

▸ [Quick Start Steps](#)

▸ [Logix Designer](#)

▸ [Module Information](#)

▴ [Instruction Set](#)

[Logix 5000 Controllers Instruction and Application Considerations](#)

[Logix Designer Application Instruction Set](#)

[Interpret the Attribute Tables Array Concepts](#)

▴ [CIP Axis Attributes](#)

[AXIS_CIP_DRIVE Diagrams](#)

[AXIS_CIP_DRIVE Structure](#)

▸ [Accessing Attributes](#)

[AC Line Condition Attributes](#)

[Acceleration Control Attributes](#)

[Acceleration Control Configuration Attributes](#)

[Additional Error Code Information](#)

▸ [APR Fault Attributes](#)

[Auto-Tune Configuration Attributes](#)

▸ [Axis Exception Action Configuration Attributes](#)

[Axis Info Attributes](#)

[Axis Safety Status Attributes](#)

[Axis Statistical Attributes](#)

[CIP Axis Status Attributes](#)

[CIP Error Codes](#)

[CIP Motion Axis Control Modes](#)

▴ [Command Reference Generation Attributes](#)

[Command Generator Configuration Attributes](#)

[Command Generator Signal Attributes](#)

[Configuration Fault Attributes](#)

[Control Mode Attributes](#)

[Converter AC Line Configuration Attributes](#)

[Converter AC Line Monitoring Attributes](#)

[Converter AC Line Source Configuration Attributes](#)

[Converter Bus Voltage Control Configuration](#)

Command Generator Configuration Attributes

The following are the command generator configuration attributes associated with a Motion Control Axis:

Skip Speed 1

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|--------------|---------|-----------|---------|-----|-----|---------------------|
| Optional - F | Set/SSV | REAL | 0 | -∞ | ∞ | Velocity Units |

The Skip Speed 1 attribute sets the central speed of a skip speed band within which the device does not operate. The skip speed value is signed.

Skip Speed 2

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|--------------|---------|-----------|---------|-----|-----|---------------------|
| Optional - F | Set/SSV | REAL | 0 | -∞ | ∞ | Velocity Units |

The Skip Speed 2 attribute sets the central speed of a skip speed band within which the device does not operate. The skip speed value is signed.

Skip Speed 3

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|--------------|---------|-----------|---------|-----|-----|---------------------|
| Optional - F | Set/SSV | REAL | 0 | -∞ | ∞ | Velocity Units |

The Skip Speed 3 attribute sets the central speed of a skip speed band within which the device does not operate. The skip speed value is signed.

Skip Speed Band

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|--------------|---------|-----------|---------|-----|-----|---------------------|
| Optional - F | Set/SSV | REAL | 0 | 0 | ∞ | Velocity Units |

When operating in Closed Loop Velocity mode, the Fine Velocity Command block also supports Skip Bands that are most frequently used in applications where certain speeds excite mechanical resonance frequencies of the motor and load.

The Skip Speed Band attribute determines the speed window around a skip speed that cannot be commanded. Any command set-point within this window is adjusted by the Skip Speed block to fall at either the upper or lower Skip Speed Band boundary value. The device can smoothly accelerate or decelerate through the skip speed band based on the ramp generator block but may not operate at a set speed within the band. The Skip Speed Band is distributed ½ above and ½ below the skip speed. This Skip Speed Band attribute applies to all skip speeds supported in the device. A value of 0 for this attribute disables this feature.

Ramp Velocity - Positive

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|-------|--------|-----------|---------|-----|-----|---------------------|
|-------|--------|-----------|---------|-----|-----|---------------------|

file:///C:/program files (x86)/rockwell software/studio 5000/help/enu/v32/rs5000/14894.htm

1/6

| | | | | | | |
|---|---------|------|---|---|---|----------------|
| | | | | | | |
| Optional - FV Derived from Max Speed | Get/SSV | REAL | 0 | 0 | ∞ | Velocity Units |

The Ramp Velocity - Positive attribute is a positive value that defines the maximum positive velocity command output of the Ramp Generator.

Ramp Velocity - Negative

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|---|---------|-----------|---------|-----|-----|---------------------|
| Optional - FV Derived from Max Speed | Get/SSV | REAL | 0 | -∞ | 0 | Velocity Units |

The Ramp Velocity - Negative attribute is a negative value that defines the maximum negative velocity command output of the Ramp Generator.

Ramp Acceleration

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|---|---------|-----------|---------|-----|-----|---------------------|
| Optional - FV Derived from Max Accel | Get/SSV | REAL | 0 | 0 | ∞ | Accel Units |

The Ramp Acceleration attribute is a positive value that defines the maximum acceleration (increasing speed) of the velocity command output by the Ramp Generator.

Ramp Deceleration

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|---|---------|-----------|---------|-----|-----|---------------------|
| Optional - FV Derived from Max Decel | Get/SSV | REAL | 0 | 0 | ∞ | Accel Units |

The Ramp Deceleration attribute is a positive value that defines the maximum deceleration (decreasing speed) of the velocity command output by the Ramp Generator.

Ramp Jerk Control

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|---------------|---------|-----------|---------|-----|-----|---------------------|
| Optional - FV | Get/SSV | REAL | 0 | 0 | 100 | % |

The Ramp Jerk Control attribute sets the percentage of accel or decel time that is applied to the speed ramp as jerk limited S Curve based on a step change in velocity. The S Curve time is added ½ at the beginning and ½ at the end of the ramp. A value of 0 results in no S-Curve, for example, a linear acceleration or deceleration ramp.

A value of 100% results in a triangular acceleration profile with the peak being the

[Attributes](#)

[Converter Bus Voltage Control Signal Attributes](#)
[Converter Control Mode Attributes](#)

[Converter Current Control Configuration Attributes](#)
[Converter Current Control Signal Attributes](#)

[Converter Current Reference Configuration Attributes](#)
[Converter Current Reference Signal Attributes](#)

[Converter Output Attributes](#)
[Converter Reactive Power Control Attributes](#)

[Converter Types](#)
[Current Control Signal Attributes](#)

[Current Control Configuration Attributes](#)
[Cyclic Read and Cyclic Write](#)

[DC Bus Condition Attributes](#)
[Device Function Codes](#)
[Device Commissioning Attributes](#)

[Drive General Purpose I/O Attributes](#)
[Drive Output Attributes](#)

[Drive Parameters](#)
[Event Capture Attributes](#)

[Exception Factory Limit Info Attributes](#)

[Exception User Limit Configuration Attributes](#)
[Exception, Fault and Alarm Attributes](#)

[Exceptions](#)
[Fault and Alarm Behavior](#)
[Feedback Interface Types](#)

[Feedback Configuration Attributes](#)

[Frequency Control Configuration Attributes](#)
[Frequency Control Signal Attribute](#)

[General Feedback Info Attributes](#)
[General Feedback Signal Attributes](#)

[General Linear Motor Attributes](#)

A value of zero results in a triangular acceleration profile that ends with the configured ramp acceleration or deceleration.

As the Jerk Control value increases the derived accelerating jerk value decreases based on:

$$0.5 * 0.01 * \text{Jerk Control} * \text{Ramp Vel Positive} / \text{Ramp Accel}$$

and the decelerating Jerk limit value also decreases according to:

$$0.5 * 0.01 * \text{Jerk Control} * \text{Ramp Vel Negative} / \text{Ramp Decel}.$$

Flying Start Enable

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|---------------|---------|-----------|---------|-----|-----|---|
| Optional - FV | Set/SSV | USINT | 0 | 0 | 1 | 0 = Flying Start Disabled 1 = Flying Start Enabled |

The Flying Start Enable attribute is used to enable or disable the Flying Start feature of the device. When Flying Start Enable is true and the motion axis is enabled, the device determines the current velocity of the motor, using either the configured Flying Start Method or, if not supported, a method that is left to the drive vendor's discretion. This operation is done as part of the Starting State initialization activities. Just prior to transitioning to the Running state, the device presets the output of the Ramp Generator to the current velocity. In this way, the motor seamlessly ramps from its current velocity to the commanded velocity from the controller. When Flying Start Enable is false, the motor velocity is irrelevant and a preset of 0 is applied to the Ramp Generator output.

Some drive vendors do not allow the Flying Start feature to be disabled when connected to a feedback device. To support this behavior, these drives do not support the Flying Start Enable attribute, but do support the Flying Start Method attribute.

Flying Start Method

| Usage | Access | Data Type | Default | Min | Max | Semantics of Values |
|---------------|---------|-----------|---------|-----|-----|---|
| Optional - FV | Set/SSV | USINT | 0 | - | - | Enumerations: 0 = Encoder Only (R) 1 = Counter EMF (O) 2 = Sweep Frequency (O) |

The Flying Start Method attribute is an enumerated value which establishes the method used to "catch" a moving motor when the drive is enabled. The configured Flying Start Method is applied if Flying Start Enable is true or if the Flying Start Enable attribute is not supported.

When Encoder Only is selected, the drive uses encoder feedback to determine the current speed of the motor to initialize the Ramp Generator output. This method is not applicable without a connected feedback device. If Encoder Only is selected without a connected feedback device, the Flying Start function is effectively disabled.

When Counter EMF is selected, the drive determines the speed of the motor by measuring the motor's Counter EMF and applying the estimated speed to the Ramp Generator output.

When Sweep Frequency is selected the drive applies an algorithm that excites the motor at a predetermined frequency and, while "sweeping" the frequency to zero, checks for the motor current to change sign when the frequency matches the speed of the motor. The drive then applies this speed to the to the Ramp Generator output.

See also

[General Motor Attributes](#)

[General Permanent Magnet Motor Attributes](#)

[General Rotary Motor Attributes](#)

[Guard Safety Attributes](#)

[Guard Safety Status Attributes](#)

[Hookup Test Configuration Attributes](#)

[Hookup Test Result Attributes](#)

[Identify Motion Axis Attributes Based on Device Function Codes](#)

[Induction Motor Attributes](#)

[Inertia Test Configuration Attributes](#)

[Inertia Test Result Attributes](#)

[Initialization Faults Attributes](#)

[Interior Permanent Magnet Motor Attributes](#)

[Linear PM Motor Attributes](#)

[Load Transmission and Actuator Attributes](#)

[Local Mode Configuration Attribute](#)

[Module/Node Fault and Alarm Attributes](#)

▷ [Motion Control Axis Behavior Model](#)

[Motion Control Configuration Attributes](#)

[Motion Control Interface Attributes](#)

[Motion Control Methods](#)

[Motion Control Modes](#)

[Motion Control Signal Attributes](#)

[Motion Control Status Attributes](#)

[Motion Database Storage Attributes](#)

[Motion Dynamic Configuration Attributes](#)

[Motion Fault and Alarm Exceptions](#)

[Motion Homing Configuration Attributes](#)

[Motion Instruction Compatibility](#)

[Motion Planner Configuration Attributes](#)

Command Generator

Command Generator Signal Attributes

[Motion Planner Output Attributes](#)

▷ [Motion Scaling Attributes](#)

[Motor Attributes](#)

[Motor Attributes Model](#)

[Motor Test Result Attributes](#)

[No Control Mode](#)

[Position Control Mode](#)

[Position Loop Signal Attributes](#)

[Position Loop Configuration Attributes](#)

[Power and Thermal Management Configuration Attributes](#)

[Power and Thermal Management Status Attributes](#)

[Replicated Attributes](#)

[Required vs. Optional Axis Attributes](#)

[Reset an APR Fault](#)

[Rockwell Automation Specific CIP Axis Alarm Names](#)

[Rockwell Automation Specific Exceptions](#)

[Rockwell Automation Specific CIP Axis Fault Names](#)

[Rockwell Automation Specific Initialization Faults](#)

[Rockwell Automation Specific Start Inhibits](#)

[Rotary PM Motor Attributes Standard CIP Axis Fault and Alarm Names](#)

[Standard Exceptions](#)

[Rotary PM Motor Attributes](#)

[Standard Initialization Faults](#)

[Standard Start Inhibits](#)

[Start Inhibits Attributes](#)

[State Behavior](#)

▷ [Stopping and Braking Attributes](#)

[Torque Control Mode](#)

[Torque/Force Control Configuration Attributes](#)

[Torque/Force Control Signal Attributes](#)

[Velocity Control Mode](#)

[Velocity Loop Configuration Attributes](#)

[Velocity Loop Signal](#)

- [velocity loop signal](#)
- [Attributes](#)
- ▷ [Module Configuration Attributes](#)
- [Bit Addressing](#)
- [Common Attributes](#)
- [Data Conversions](#)
- [Elementary data types](#)
- [LINT data types](#)
- [Floating Point Values](#)
- [Immediate values](#)
- [Index Through Arrays](#)
- [Math Status Flags](#)
- [Motion Error Codes \(.ERR\)](#)
- [Structures](#)
- ▷ [Equipment Sequence instructions](#)
- ▷ [Equipment Phase Instructions](#)
- ▷ [Alarm Instructions](#)
- ▷ [Advanced Math Instructions](#)
- ▷ [Array \(File\)/Misc Instructions](#)
- ▷ [Array \(File\)/Shift Instructions](#)
- ▷ [ASCII Conversion Instructions](#)
- ▷ [ASCII Serial Port Instructions](#)
- ▷ [ASCII String Instructions](#)
- ▷ [Bit Instructions](#)
- ▷ [Compare Instructions](#)
- ▷ [Debug Instructions](#)
- ▷ [Drives Instructions](#)
- ▷ [Drive Safety Instructions](#)
- ▷ [For/Break Instructions](#)
- ▷ [Filter Instructions](#)
- ▷ [Function Block Attributes](#)
- ▷ [Structured Text Attributes](#)
- ▷ [Compute/Math Instructions](#)
- ▷ [Move/Logical Instructions](#)
- ▷ [Input/Output Instructions](#)
- ▷ [License Instructions](#)
- ▷ [Math Conversion Instructions](#)
- ▷ [Metal Form Instructions](#)
- ▷ [Motion Configuration Instructions](#)
- ▷ [Motion Event Instructions](#)
- ▷ [Motion Group Instructions](#)
- ▷ [Motion Move Instructions](#)
- ▷ [Motion State Instructions](#)
- ▷ [Multi-Axis Coordinated Motion Instructions](#)
- ▷ [Logical and Move Instructions](#)
- ▷ [Program Control Instructions](#)
- ▷ [Sequencer Instructions](#)
- ▷ [Special Instructions](#)
- ▷ [Timer and Counter](#)

- ✓ [Timer and Counter Instructions](#)
- ▷ [Trigonometric Instructions](#)
- ▷ [Process Control Instructions](#)
- ▷ [Select/Limit Instructions](#)
- ▷ [Sequential Function Chart \(SFC\) Instructions](#)
- ▷ [Statistical Instructions](#)
- ▷ [Safety Instructions](#)
- ▷ [Studio 5000 Logix Designer Glossary](#)

Copyright © 2019 Rockwell Automation Technologies, Inc. All Rights Reserved.

[How are we doing?](#)