

[Instruction Set](#) > [CIP Axis Attributes](#) > Motion Database Storage Attributes

Search

- ▷ [Quick Start Steps](#)
- ▷ [Logix Designer](#)
- ▷ [Module Information](#)
- ◀ [Instruction Set](#)

[Logix 5000 Controllers](#)

[Instruction and Application Considerations](#)

[Logix Designer Application Instruction Set](#)

[Interpret the Attribute Tables](#)

[Array Concepts](#)
- ◀ [CIP Axis Attributes](#)

[AXIS_CIP_DRIVE Diagrams](#)

[AXIS_CIP_DRIVE Structure](#)

▷ [Accessing Attributes](#)

[AC Line Condition Attributes](#)

[Acceleration Control Attributes](#)

[Acceleration Control Configuration Attributes](#)

[Additional Error Code Information](#)

▷ [APR Fault Attributes](#)

[Auto-Tune Configuration Attributes](#)

▷ [Axis Exception Action Configuration Attributes](#)

[Axis Info Attributes](#)

[Axis Safety Status Attributes](#)

[Axis Statistical Attributes](#)

[CIP Axis Status Attributes](#)

[CIP Error Codes](#)

[CIP Motion Axis Control Modes](#)

▷ [Command Reference](#)

[Generation Attributes](#)

[Configuration Fault Attributes](#)

[Control Mode Attributes](#)

[Converter AC Line Configuration Attributes](#)

[Converter AC Line Monitoring Attributes](#)

[Converter AC Line Source Configuration Attributes](#)

[Converter Bus Voltage Control Configuration Attributes](#)

[Converter Bus Voltage Control Signal Attributes](#)

[Converter Control Mode Attributes](#)

Motion Database Storage Attributes

The following are the Motion Database Storage attributes associated with a Motion Control Axis.

System Acceleration Base

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - C	Set		REAL	0 DB	0	∞	Motor Units/sec ² @ 100 % Rated

This floating point value represents the acceleration of the selected unloaded motor based on 100% Rated current and used to compute System Inertia. This attribute is used to store the original System Acceleration value for subsequent upload.

Drive Model Time Constant Base

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - C	Set		REAL	.0015 DB	0	∞	Sec

This floating point value represents the lumped model time constant associated with the drive device for the purposes of computing loop gains. This attribute is used to store the original Drive Model Time Constant value for subsequent upload. The Drive Model Time Constant Base (DMTC_Base) is computed based on the current loop bandwidth, the velocity loop update time and the feedback sample period according to the following formula:

DMTC_Base = 2 * 1/(2*PI*Current Loop Bandwidth(Hz)) + Velocity Loop Update Period + Feedback Sample Period/2

Drive Rated Peak Current

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - C	Set		REAL	0 DB	0	∞	Amps

This floating point value represents the peak current rating associated with the drive device and used to compute peak torque and acceleration limits. This attribute is used to store the original Drive Rated Peak Current value for subsequent upload.

Bus Overvoltage Operational Limit

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Optional - C	Set		REAL	0 DB	0	∞	Volts

This floating point value represents the maximum DC Bus voltage level that can be

sustained during drive operation, which is used to calculate the factory default value for PM Motor Rotary Bus Overvoltage Speed or the PM Motor Linear Bus Overvoltage Speed associated with PM motor types. This attribute is used to store the Bus Overvoltage Operational Limit value used in this calculation for subsequent upload.

Converter Model Time Constant Base

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Optional - C	Set		REAL	0.001 DB	0		Seconds

This floating point value represents the lumped model time constant associated with the regenerative converter device for the purposes of computing loop gains. This attribute is used to store the original Converter Model Time Constant value for subsequent upload. The Converter Model Time Constant Base is computed based on the converter current loop bandwidth, the bus voltage loop update time and the bus voltage feedback sample period according to the following formula:

$$CMTC_Base = 2 * 1/(2*PI*Current\ Loop\ Bandwidth(Hz)) + Bus\ Voltage\ Loop\ Update\ Period$$

Converter Current Loop Bandwidth Base

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - G	Set		REAL	0 DB	0		Hz

This floating point value represents the default bandwidth for the active and reactive current loops for the regenerative converter. This attribute is used to store the original default Converter Current Loop Bandwidth value that was used to compute the Converter Model Time Constant that is the basis for tuning the converter.

Converter Rated Current

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - G	Set		REAL	0 DB	0		Amps

This floating point value represents the continuous output current rating associated with the regenerative converter and used to compute the System Capacitance scaling attribute value from the Total Capacitance of the DC Bus. This attribute is used to store the original Converter Rated Current value for subsequent upload.

Converter Rated Peak Current

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - G	Set		REAL	0 DB	0		Amps

This floating point value represents the peak output current rating associated with the regenerative converter and used together with the Converter Rated Current to compute the default Converter Current Vector Limit attribute value. This attribute is used to store the original Converter Rated Peak Current value for subsequent upload.

Converter Rated Voltage

[Attributes](#)

[Converter Current Control Configuration Attributes](#)

[Converter Current Control Signal Attributes](#)

[Converter Current Reference Configuration Attributes](#)

[Converter Current Reference Signal Attributes](#)

[Converter Output Attributes](#)

[Converter Reactive Power Control Attributes](#)

[Converter Types](#)

[Current Control Signal Attributes](#)

[Current Control Configuration Attributes](#)

[Cyclic Read and Cyclic Write](#)

[DC Bus Condition Attributes](#)

[Device Function Codes](#)

[Device Commissioning Attributes](#)

[Drive General Purpose I/O Attributes](#)

[Drive Output Attributes](#)

[Drive Parameters](#)

[Event Capture Attributes](#)

[Exception Factory Limit Info Attributes](#)

[Exception User Limit Configuration Attributes](#)

[Exception, Fault and Alarm Attributes](#)

[Exceptions](#)

[Fault and Alarm Behavior](#)

[Feedback Interface Types](#)

[Feedback Configuration Attributes](#)

[Frequency Control](#)

[Configuration Attributes](#)

[Frequency Control Signal Attribute](#)

[General Feedback Info Attributes](#)

[General Feedback Signal Attributes](#)


[General Linear Motor Attributes](#)

[General Motor Attributes](#)

[General Permanent Magnet Motor Attributes](#)


[General Rotary Motor](#)

Converter Rated Voltage

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - G	Set		REAL	0 DB	0		Volts (RMS)


This floating point value represents the input voltage rating associated with the regenerative converter and used to compute the Bus Voltage Set Point attribute value. This attribute is used to store the original Converter Rated Voltage value for subsequent upload.

Converter DC Bus Capacitance

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - G	Set		REAL	0 DB	0		µF (Amps)


This floating point value represents the internal bus capacitance of the regenerative converter and is used to compute the System Capacitance scaling attribute. This attribute is used to store the original Converter DC Bus Capacitance value for subsequent upload.

Converter Rated Power

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - G	Set		REAL	0 DB	0		kVA


This floating point value represents the power rating of the converter. This attribute is used to estimate the default AC Line Source Power value.

Current Loop Bandwidth Scaling Factor

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - C	Set		REAL	0 DB	0		

This floating point value represents the scaling factor, based on motor type, which is used to set the factory default value for Torque Loop Bandwidth. This attribute is used to store the original Current Loop Bandwidth Scaling Factor value for subsequent upload.

Drive Rated Voltage

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - D	Set		REAL	0 DB	0		V _{rms}

This floating point value represents the RMS voltage rating of the drive that is used to set the factory default value for the Break Voltage associated with V/Hz drives. This attribute is used to store the original Drive Rated Voltage value for subsequent upload.

Max Output Frequency

[Attributes](#)

[Guard Safety Attributes](#)

[Guard Safety Status](#)

[Attributes](#)

[Hookup Test Configuration](#)

[Attributes](#)

[Hookup Test Result](#)

[Attributes](#)

[Identify Motion Axis](#)

[Attributes Based on Device](#)

[Function Codes](#)

[Induction Motor Attributes](#)

[Inertia Test Configuration](#)

[Attributes](#)

[Inertia Test Result](#)

[Attributes](#)

[Initialization Faults](#)

[Attributes](#)

[Interior Permanent Magnet](#)

[Motor Attributes](#)

[Linear PM Motor Attributes](#)

[Load Transmission and](#)

[Actuator Attributes](#)

[Local Mode Configuration](#)

[Attribute](#)

[Module/Node Fault and](#)

[Alarm Attributes](#)

▷ [Motion Control Axis](#)

[Behavior Model](#)

[Motion Control](#)

[Configuration Attributes](#)

[Motion Control Interface](#)

[Attributes](#)

[Motion Control Methods](#)

[Motion Control Modes](#)

[Motion Control Signal](#)

[Attributes](#)

[Motion Control Status](#)

[Attributes](#)

[Motion Database Storage](#)

[Attributes](#)

[Motion Dynamic](#)

[Configuration Attributes](#)

[Motion Fault and Alarm](#)

[Exceptions](#)

[Motion Homing](#)

[Configuration Attributes](#)

[Motion Instruction](#)

[Compatibility](#)

[Motion Planner](#)

[Configuration Attributes](#)

[Motion Planner Output](#)


[Attributes](#)

▷ [Motion Scaling Attributes](#)

[Motor Attributes](#)

[Motor Attributes Model](#)

Max Output Frequency

Usage	Access	T	Data Type	Default	Min	Max	Semantics of Values
Required - D	Set		REAL	0 DB	0		Hz

This floating point value represents the maximum frequency rating of the drive that is used to set the factory default values for Velocity Limits. This attribute is used to store the original Max Output Frequency value for subsequent upload.

See also

[Auto-Tune Configuration Attributes](#)

[Motor Test Result Attributes](#)

[Hookup Test Result Attributes](#)

[Inertia Test Result Attributes](#)

[Converter Bus Voltage Control Configuration Attributes](#)

[Motor Attributes Model](#)

[Motor Test Result Attributes](#)

[No Control Mode](#)

[Position Control Mode](#)

[Position Loop Signal Attributes](#)

[Position Loop Configuration Attributes](#)

[Power and Thermal Management Configuration Attributes](#)

[Power and Thermal Management Status Attributes](#)

[Replicated Attributes](#)

[Required vs. Optional Axis Attributes](#)

[Reset an APR Fault](#)

[Rockwell Automation Specific CIP Axis Alarm Names](#)

[Rockwell Automation Specific Exceptions](#)

[Rockwell Automation Specific CIP Axis Fault Names](#)

[Rockwell Automation Specific Initialization Faults](#)

[Rockwell Automation Specific Start Inhibits](#)

[Rotary PM Motor Attributes Standard CIP Axis Fault and Alarm Names](#)

[Standard Exceptions](#)

[Rotary PM Motor Attributes](#)

[Standard Initialization Faults](#)

[Standard Start Inhibits](#)

[Start Inhibits Attributes](#)

[State Behavior](#)

▷ [Stopping and Braking Attributes](#)

[Torque Control Mode](#)

[Torque/Force Control Configuration Attributes](#)

[Torque/Force Control Signal Attributes](#)

[Velocity Control Mode](#)

[Velocity Loop Configuration Attributes](#)

[Velocity Loop Signal Attributes](#)

▷ [Module Configuration Attributes](#)

[Bit Addressing](#)

[Common Attributes](#)

[Data Conversions](#)

[Elementary data types](#)

[LINT data types](#)

[Floating Point Values](#)

[Immediate values](#)

[Index Through Arrays](#)

[Math Status Flags](#)

[Motion Error Codes \(.ERR\)](#)

[Structures](#)

- ▷ [Equipment Sequence instructions](#)
- ▷ [Equipment Phase Instructions](#)
- ▷ [Alarm Instructions](#)
- ▷ [Advanced Math Instructions](#)
- ▷ [Array_\(File\)/Misc Instructions](#)
- ▷ [Array_\(File\)/Shift Instructions](#)
- ▷ [ASCII Conversion Instructions](#)
- ▷ [ASCII Serial Port Instructions](#)
- ▷ [ASCII String Instructions](#)
- ▷ [Bit Instructions](#)
- ▷ [Compare Instructions](#)
- ▷ [Debug Instructions](#)
- ▷ [Drives Instructions](#)
- ▷ [Drive Safety Instructions](#)
- ▷ [For/Break Instructions](#)
- ▷ [Filter Instructions](#)
- ▷ [Function Block Attributes](#)
- ▷ [Structured Text Attributes](#)
- ▷ [Compute/Math Instructions](#)
- ▷ [Move/Logical Instructions](#)
- ▷ [Input/Output Instructions](#)
- ▷ [License Instructions](#)
- ▷ [Math Conversion Instructions](#)
- ▷ [Metal Form Instructions](#)
- ▷ [Motion Configuration Instructions](#)
- ▷ [Motion Event Instructions](#)
- ▷ [Motion Group Instructions](#)
- ▷ [Motion Move Instructions](#)
- ▷ [Motion State Instructions](#)
- ▷ [Multi-Axis Coordinated Motion Instructions](#)
- ▷ [Logical and Move Instructions](#)
- ▷ [Program Control Instructions](#)
- ▷ [Sequencer Instructions](#)
- ▷ [Special Instructions](#)
- ▷ [Timer and Counter Instructions](#)
- ▷ [Trigonometric Instructions](#)
- ▷ [Process Control Instructions](#)

- ▷ [Select/Limit Instructions](#)
- ▷ [Sequential Function Chart \(SFC\) Instructions](#)
- ▷ [Statistical Instructions](#)
- ▷ [Safety Instructions](#)
- ▷ [Studio 5000 Logix Designer Glossary](#)

Copyright © 2019 Rockwell Automation Technologies, Inc. All Rights Reserved.

[How are we doing?](#)