

Advanced Servo Motion Mastery

plcsupport@onlineplcsupport.com

Section: 1 Introduction ▶ 1. Introduction 07:42 <input type="radio"/>	1 / 1	Section: 7 Servo Accel and Decel Jerks ▶ 17. Servo Accel Explained 14:02 <input type="radio"/> ▶ 18. Servo S-Curve Jerks Explained 09:45 <input type="radio"/>	0 / 2
Section: 2 Advanced Servo Motion Mastery Downloads Conversion Process ▶ 2. File Conversion 02:22 <input type="radio"/>	0 / 1	Section: 8 Intro to Servo Conversion Constants ▶ 19. Using the Conversion Constants Calculate Tool 21:21 <input type="radio"/> ▶ 20. Understand a Simple Mechanical Drive System and Convert 10:46 <input type="radio"/>	0 / 2
Section: 3 Emulation Module ▶ 3. Understanding Emulator 06:12 <input type="radio"/> ▶ 4. Emulation From Scratch 03:40 <input type="radio"/> █ Servo_Motion_Mastery_101_V20Emulated.ACD.txt ▶ 5. Studio 5000 Emulation 05:48 <input type="radio"/> █ Servo_Motion_Mastery_101_V28Emulated.ACD.txt ▶ 6. Emulating Gear Change Logic 05:25 <input type="radio"/> ⚡ Quiz 1: Emulation Quiz <input type="radio"/>	0 / 5	Section: 9 Understanding Servo Cams ▶ 21. The Difference Between Linear Cams and Cubic Cams 17:57 <input type="radio"/> ▶ 22. Using a Servo Cam Editor 25:09 <input type="radio"/> ▶ 23. Final Summary of Servo Cams 06:34 <input type="radio"/> █ ServoMastery_SimpleMATC_Emulated.ACD.txt	0 / 3
Section: 4 Understanding Servo Rings ▶ 7. Troubleshooting a Servo Ring 16:11 <input type="radio"/> ▶ 8. Servo Motion Mastery Inhibiting An Axis 13:49 <input type="radio"/> ▶ 9. Servo Motion Mastery Inhibiting A Kinetix 6000 Drive 08:01 <input type="radio"/> ▶ 10. Servo Motion Mastery Motor Removal TroubleShooting 15:16 <input type="radio"/>	0 / 4	Section: 10 Servo Motion Mastery MATC Module ▶ 24. Motion Axis Time Cam Instruction Intro 27:21 <input type="radio"/> █ MATC_Intro.ACD.txt ▶ 25. Breakdown the Difference Between a Immediate and Pending MATC Use 25:13 <input type="radio"/> █ TimingCAMs.ACD.txt ▶ 26. MATC Logic Used With a Virtual Axis With TroubleShooting 16:02 <input type="radio"/> █ TimingCAMsEmulation.ACD.txt ▶ 27. MATC Scaling Explained To Limit Confusion 15:13 <input type="radio"/> ▶ 28. MATC Instruction With A Natural Move Command 12:40 <input type="radio"/> █ SimpleMATC_WithMove.ACD.txt	0 / 5
Section: 5 Understanding System Timing and Why ▶ 11. Course Rate Update Timing or Better Known as (CUP) 14:34 <input type="radio"/> ▶ 12. Periodic Task vs Continuous Task 19:48 <input type="radio"/>	0 / 2		
Section: 6 Servo Testing and Tuning ▶ 13. Servo Commissioning Test 07:09 <input type="radio"/> ▶ 14. Servo Motion Mastery Trending A Servo HookUp Test 11:22 <input type="radio"/> ▶ 15. Quick Start to Servo Tuning 34:53 <input type="radio"/> ▶ 16. Tuning an S-Curve Movement from an Instruction 21:35 <input type="radio"/>	0 / 4		

<p>Section: 11 0 / 9</p> <p>Servo Motion Mastery PCAM Module</p> <ul style="list-style-type: none"> ▶ 29. Servo Motion Mastery PCAM Intro 10:11 <input type="radio"/> ▶ 30. Servo Mastery PCAM Explained In Detail 15:59 <input type="radio"/> PCAM_Intro_Emulated.ACD.txt ▶ 31. Building a PCAM From Scratch 01:15:05 <input type="radio"/> ServoAxis_PositionCam.ACD.txt ▶ 32. MAPC Common Issue With Master Reference 11:30 <input type="radio"/> PCAM_Intro.ACD.txt ▶ 33. MAPC PC Bit explained 08:09 <input type="radio"/> ▶ 34. MAPC Adding Common Health Checks 22:11 <input type="radio"/> PCAM_Intro_WithHealthChecks.ACD.txt ▶ 35. Use scaling in an MAPC instruction 16:13 <input type="radio"/> ▶ 36. MAPC Cam Lock Position Function Talk - Not program and Show 05:25 <input type="radio"/> ▶ 37. MAPC Master Lock Position Function - Not program and Show 17:41 <input type="radio"/> 	<p>Section: 15 0 / 8</p> <p>Servo Motion Mastery MAOC Module</p> <ul style="list-style-type: none"> ▶ 48. MAOC Introduction 13:39 <input type="radio"/> ▶ 49. MAOC Cam Explained 04:55 <input type="radio"/> ▶ 50. MAOC Cam Output Control 09:32 <input type="radio"/> ▶ 51. MAOC Compensation Usage Explained 14:21 <input type="radio"/> ▶ 52. MAOC Input Enable Feature to Disarm or Arm Outputs 18:04 <input type="radio"/> ▶ 53. MAOC Axis Setup - Avoid an ERR 35 code 14:57 <input type="radio"/> MAOC_ServoMastery_Emulation.ACD.txt MAOC_ServoMastery_EmulationV30.ACD.txt MAOC_ServoMastery_EmulationV28.ACD.txt MAOC_ServoMastery_EmulationLinearV28.ACD.txt MAOC_ServoMastery_EmulationRotaryV28.ACD.txt ▶ 54. MAOC Cam Used In a Linear Simple Application 08:08 <input type="radio"/> MAOC_ServoMastery_EmulationLinearV28.ACD.txt ▶ 55. MAOC Code Explained 09:10 <input type="radio"/> MAOC_ServoMastery.ACD.txt
<p>Section: 12 0 / 2</p> <p>Difference in a Position System And A Time System</p> <ul style="list-style-type: none"> ▶ 38. Difference In A MAPC and a MATC 10:09 <input type="radio"/> Quiz 2: MATC or MAPC <input type="radio"/> 	<p>Section: 16 0 / 1</p> <p>Understanding Velocity StandStill</p> <ul style="list-style-type: none"> ▶ 56. Using a Axis StandStill Bit 12:26 <input type="radio"/>
<p>Section: 13 0 / 6</p> <p>MAPC Cam Blending - Hardest Task for Most people</p> <ul style="list-style-type: none"> ▶ 39. Starting from scratch 13:02 <input type="radio"/> ▶ 40. Setting up the Physical Axis 18:17 <input type="radio"/> ▶ 41. Adding elements for the state controls 09:19 <input type="radio"/> ▶ 42. Adding our first MAPC 19:22 <input type="radio"/> ▶ 43. Adding the second MAPC for Cam blending 15:23 <input type="radio"/> ▶ 44. Showing a more in-depth view of the Cams blended with added features 23:30 <input type="radio"/> 	<p>Section: 17 0 / 4</p> <p>Coordinated Motion Section Cartesian Module</p> <ul style="list-style-type: none"> ▶ 57. Intro to a Coordinated Motion System 09:52 <input type="radio"/> ▶ 58. Coordinated Motion Section MCCM Instruction Example 16:57 <input type="radio"/> ▶ 59. Coordinated Motion Section MCLM Instruction Example 16:28 <input type="radio"/> ▶ 60. Coordinated Motion Section Cartesian System Logic Explained 46:53 <input type="radio"/> Coord_Motion_Bland_Circle_Diamond_Square.ACD.txt
<p>Section: 14 0 / 3</p> <p>Motion Cam Calculate Profile Instruction or MCCP Instruction Module</p> <ul style="list-style-type: none"> ▶ 45. Using an MCCP Instruction 12:40 <input type="radio"/> ▶ 46. MCCP Instruction - Using Cam Elements 15:02 <input type="radio"/> ▶ 47. Using an MCCP then loading it into an MAPC instruction for use 15:29 <input type="radio"/> <p>Servo_Motion_Mastery_101_IoVersion.ACD.txt</p>	<p>Section: 18 0 / 1</p> <p>Closing Comments....Intro to Advanced Servo Mastery 2</p> <ul style="list-style-type: none"> ▶ 61. Closing Comments 07:38 <input type="radio"/>

Contents

Lecture 1: Introduction	5
Lecture 2: File Conversion.....	5
Lecture 3: Understanding Emulator	6
Lecture 4: Emulation from Scratch	8
Lecture 5: Studio 5000 Emulation.....	10
Lecture 6: Emulating Gear Change Logic	11
Lecture 7: Troubleshooting a Servo Ring	11
Lecture 8: Inhibiting an Axis.....	17
Lecture 9: Inhibiting a kinetic 6000 Drive	18
Lecture 10: Motor Removal Troubleshooting	19
Lecture 11: Course Rate Update Timing (CUP)	20
Lecture 12: Tasks, Periodic and Continuous	20
Lecture 14: Trending a Servo Hookup Test	22
Lecture 15: Quick Start to Servo Tuning	23
Lecture 16: Tuning an S-Curve Movement from an Instruction	26
Lecture 17: Servo Acceleration Explained.....	27
Lecture 18: Servo S-Curve Jerks Explained.....	27
Lecture 19: Using the Conversion Constants Calculate Tool	28
20. Understand a Simple Mechanical Drive System and Convert	32
21. The Difference Between Linear Cams and Cubic Cams	33
22. Using a Servo Cam Editor.....	35
24. Motion Axis Time Cam Instruction Intro	36
25. Breakdown the Difference Between an Immediate and Pending MATC Use.....	41
26. MATC Logic Used with a Virtual Axis With Trouble Shooting.....	43
27. MATC Scaling Explained To Limit Confusion	45
28. MATC Instruction With A Natural Move Command	46
29. Servo Motion Mastery PCAM Intro	48
30. Servo Mastery PCAM Explained In Detail.....	53
31. Building a PCAM From Scratch.....	55
32. MAPC Common Issue With Master Reference	72
33. MAPC PC Bit explained	72
34. MAPC Adding Common Health Checks	72
35. Use scaling in an MAPC instruction.....	74
36. MAPC Cam Lock Position Function Talk - Not program and Show	75
37. MAPC Master Lock Position Function - Not program and Show	75
38. Difference In A MAPC and a MATC	76

39. Starting from Scratch	77
40. Setting up the Physical Axis	79
41. Adding elements for the state controls	80
42. Adding our first MAPC	83
43. Adding the Second MAPC for Cam Bending.....	89
44. Showing a More In-Depth View of the Cams Blended with Added Features	91
45. Using the MCCP Instruction	93
47. Using a MCCP and then Loading it into an MAPC Instruction For Use	94
48. MAOC Introduction.....	96
50. MAOC Cam Output Control	99
51. MAOC Compensation Usage Explained	100
52. MAOC Input Enable Feature (Input Cam)	105
53. MAOC Axis Setup - Avoid an ERR	108
54. MAOC Cam Used In a Linear	110
55. MAOC Code Explained	111
56. MAOC Update.....	112
57. Using a Axis StandStill Bit.....	115
58. Intro to a Coordinated Motion.....	116
59. Coordinated Motion Section.....	120
60. Coordinated Motion Section.....	123
Dwells	123
Zero Length Move	123
61. Coordinated Motion Section.....	125
62. Kinetix 6000 Inputs	128
63. Understanding Servo Registration	129
64. Length Detection Example (A deeper look into Registration)	130

Lecture 1: Introduction





Lecture 2: File Conversion

Simply rename the .txt file .ACD. Do not open or edit at all while it is a .txt. If you even open it in notepad it will be ruined, redownload.

Lecture 3: Understanding Emulator


The version of the emulator must match the firmware version of your Logix Designer project.

To add a ‘board’ right click an open rack position and select create. Then select the board from the list of options. In this case we select ‘Controller’.



Lecture 4: Emulation from Scratch


From the RSLogix compiler create a new project and select processor type ‘Emulate’.



The below listed files are available in the course folder.

- MATC_Intro.ACD.txt
- PCAM_Intro_Emulated.ACD.txt
- Servo_Motion_Mastery_101.ACD.txt
- ServoAxis_PositionCam.ACD.txt
- ServoMastery_SimpleMATC_Emulated.ACD.txt
- TimingCAMs.ACD.txt
- TimingCAMsEmulation.ACD.txt

The screenshot shows the 'Controller Organizer' window on the left and the 'Controller Properties - Prcatice_Emulate' dialog box on the right. The 'Controller Organizer' tree view includes 'Controller Prcatice_Emulate', 'Tasks', 'Motion Groups', 'Data Types', 'Trends', and 'I/O Configuration'. The 'I/O Configuration' node has a child '1756 Backplane, 1756-A10' which contains '[1] Emulator Prcatice_Emulate'. The 'Controller Properties' dialog box has tabs for Date/Time, Advanced, SFC Execution, File, Memory, and Security. The 'General' tab is selected, showing 'Vendor: Allen-Bradley', 'Type: Emulator RSLogix Emulate 5000 Controller', 'Revision: 20.11', 'Name: Prcatice_Emulate', 'Description: ', 'Chassis Type: 1756-A10 10-Slot ControlLogix Chassis', and 'Slot: 1'. Buttons for 'OK', 'Cancel', 'Apply', and 'Help' are at the bottom.



Use Who Active to download to the running emulator.

At this point you can create a project as you normally would and run it.


Lecture 5: Studio 5000 Emulation

Pretty much the same as the RSLogix version.




Lecture 6: Emulating Gear Change Logic


This section is more about downloading a project to the emulator, nothing about gear changing logic.



Lecture 7: Troubleshooting a Servo Ring

Here we are talking about the proper setup of a servo ring what happens with a servo ring or CIP servo ring when the processes are powering up or when they are downloaded or whatever else the case may be. Begin by adding a motion card.







Next we want to add our motion controller (amp) under the SERCOS comm card.

Category	Description	Model	Vendor	Drive	
2094-BC01-M01	Kinetix 6000, 460VAC, IAM, 6kW PS, 9A Cont., 13A P...	2094-BC01-M01	Kinetix 6000, 460VAC, IAM, 6kW PS, 9A Cont., 13A Peak	Allen-Bradley	Drive
2094-BC01-MP5	Kinetix 6000, 460VAC, IAM, 6kW PS, 4A Cont., 6A Peak	2094-BC01-MP5	Kinetix 6000, 460VAC, IAM, 6kW PS, 4A Cont., 6A Peak	Allen-Bradley	Drive


Remember that the node number you configure the driver for is whatever number you have dialed in on the front of the amp.




Now we want to create a motion group and add an axis of type AXIS_SERVO_DRIVE.




And then link the servo axis and the controller together.



Now add the motor that you are using.



Under controller properties Date/Time check Enable Time Synchronization.



The below table represents the natural scan order of the SERCOS. Active nodes refer to other motion controllers you may have on the network. Node = controller. Step 3 checks the nodes found on the network against those you have configured in the software. Step 4 is making sure you have your axis setup properly.

The effect of an error is that the SERCOS system does not transition states. Watch the Status box in the lower left area to monitor the state transitions. You can also select the axis name under Motion Group to check the fault status of that equipment.

Sercos System

0 = Looking for ring

1 = Looking for Active Nodes


2 = Configuration Communication

3 = Configuration Nodes

4 = Configured Axis

Note: if stuck in a state then open the quick view panel to see the axis state|

If everything has gone well you are ready to start and operate the axis.



You can also view the numerical sequence on the front of the drive.

Fault message example.

The screenshot shows the SIMATIC Manager software interface. In the left pane, under 'I/O Configuration', there is a tree view of modules. One module, '[2] 1756-M16SE Sercos', is highlighted with a blue background and has a yellow warning icon. A red dashed arrow points from this module down to a table in the right pane. The table has four rows:

Description	
Status	IO Faulted
Cycle Time	2.0 ms
Module Fault	(Code 16#fd05) Connection Request Error: No axis or group assigned.

Here is the ring sequence for CIP systems.

CIP Systems

0 = Initializing 6 = Stopping

1 = Pre-Charge 7 = Aborting

2 = Stopped 8 = Faulted

3 = Starting 9 = Start Inhibited

4 = Running 10 = Shutdown

5 = Testing

Lecture 8: Inhibiting an Axis

We are not talking about the servo controller hardware, rather we are talking about the servo axis in the motion group. Although in some cases you can inhibit the hardware by going to the properties dialog and selecting that check box. This topic is covered in another lesson.

So now we are going to look at a method by which you can **inhibit a servo axis by means of a function in your ladder program**. We do this using the SSV, setting system value.


SSV to Inhibit Axis

Class: Axis

Instance: Axis01 (the name of the axis in our motion group we wish to inhibit)

Attribute: Inhibit Axis


Source: (you must put in a tag, cannot use a digit. This is likely a tag you create for this purpose)



So we have put in a couple of move statements to load the AxisEnableDisable tag with 1 or 0 which triggers the function.

When we run the function and load the tag with a 1 we see that the axis is inhibited.

Type	AXIS_SERVO_DRIVE
Description	
Axis State	Inhibited
Drive Name	MotionAxis_1
Node	10
Axis Fault	No Faults



Now we will look at disabling the hardware component.

SSV to Inhibit Axis

Class: Module
 Instance: ModuleAxis_1 (the name of the axis in our motion group we wish to inhibit)
 Attribute: Mode
 Source: (you must put in a tag, cannot use a digit. This is likely a tag you create for this purpose)

Result is a processor fault.





Lecture 9: Inhibiting a kinetic 6000 Drive

In this lecture we will concentrate on how to inhibit the module (hardware) itself. We are not going to do this by means of the property dialog (this method is not always available). We will use a code implementation. [the “CurrentMode” tag is not available in all drives, check, your looking for inhibit/shutdown]


SSV to Inhibit Axis

Class: Module
 Instance: ModuleAxis_1 (the name of the axis in our motion group we wish to inhibit)
 Attribute: Mode
 Source: Kinteix6000_CurrentMode

In this case changing the tag to the value 4 inhibits the drive.



22




(End)

Lecture 10: Motor Removal Troubleshooting

If an axis is inhibited and then goes into fault the system continues on, it is not concerned and is still fully functional. The IO Not Responding is good, not flashing.

But once we enable the axis if the fault still exist the system will indicate so and the IO Not Responding LED will blink.

As an example, we will remove the motor from our hardware configuration.



Type	AXIS_SERVO_DRIVE
Description	
Axis State	Inhibited
Drive Name	MotionAxis_1
Node	10
Axis Fault	PhysicalAxisFault
Drive Fault	MotFeedbackFault, FeedbackFault
Module Faults	No Faults
Attribute Error	No Faults

Type	AXIS_SERVO_DRIVE
Description	
Axis State	Faulted
Drive Name	MotionAxis_1
Node	10
Axis Fault	PhysicalAxisFault
Drive Fault	MotFeedbackFault, FeedbackFault
Module Faults	No Faults
Attribute Error	No Faults

At this point the axis is no longer faulted, the application understands there is no motor for the faulted drive to affect so it continues on. This can be handy in troubleshooting. When trying to track down an axis fault you can try removing the motor. If the axis comes back up as okay you may have a motor problem that was causing the axis fault.

Now we know how to disable an axis, disable the drive, and remove the motor from the possibilities.

Lecture 11: Course Rate Update Timing (CUP)

Whenever an application is using motion the first routine(s) processed is the motion group and the associated axis. The frequency at which the axis routines are solved is based on the CUP. The **Course Rate Update (CUP)** is defined as the milliseconds it takes to scan all the servos in the motion group, solve the logic, and update the drive positions, rates, torque, etc. This is how long that process takes. It is updated in .5 ms increments.

To determine the value you should use, a good rule of thumb is 1 ms per virtual axis, 0.5 ms per axis servo drive, and 2.0 ms per SERCOS physical axis. You may want to round up a ms.





Figure 1 Attribute tab of the Motion Group Properties.

Servo Drives (physical drives)

If running an **L7 processor** you can drop it down to 0.25 ms per axis.
If running an **L6 processor** you can drop it down to 0.5 ms per axis.
If running an **L55 processor** you can drop it down to 1.5 ms per axis.
If running an **L5 processor** you can drop it down to 2.0 ms per axis.



The above table assumes periodic task scanning. This is an interrupt with resume process.


L8 is a newer generation of drive and is likely faster than the rates above.

Needless to say improper timing entries can be a source of faults.


Lecture 12: Tasks, Periodic and Continuous

Keep in mind it is a two step process to execute a servo command; the first cycle will write the command it wants the drive to execute and the second cycle will execute the command.

A good idea is to have your axis processed at least 4 times faster (as often) than the other tasks not associated with servos.




On the **Monitor** tab of any tasks properties dialog you can check the actual scan time for that task.



On a SERCOS card you can check and adjust the **Requested Packet Interval** under the Connection tab.

Lecture 13: Servo Commissioning Testing

Axis properties **Hookup** tab.



Marker Test: turn the motor shaft, the servo will determine the direction and make note. This is testing the marker of the decoder. When you press the button you will see the below dialog. When you turn the shaft the text "Executing" will change to "Command Complete".




Test Feedback: enter a value for Test Increment in Position Units then press **APPLY** and then click the Test Feedback button. You are going to have to rotate the shaft that distance so do not enter too large a number. Once the drive has made the reading the "Executing" text will change to "Command Complete". The result is that the feedback polarity is determined by the drive.

Test Command and Feedback: what this is going to do is turn the servo on and slowly increase the speed through a full rotation so that it can record the commutation. During this test watch the motor and confirm it is moving in the correct direction. The software will ask if the motor turned in the correct direction and it will adjust itself whether you say yes or no.

Lecture 14: Trending a Servo Hookup Test


Create a new trend, call it Hookup_Test. From chart properties Pens tab you can add the pen Axis01.ActualPosition. Set the x-axis to 15 seconds.




Before you begin running the axis use the motion direct commands to home the axis (MAH). At this point you are ready to run the hookup test. Run all three tests from the previous lecture.

Lecture 15: Quick Start to Servo Tuning

Here we will auto tune the motor. Often times it is best to have an uncoupled motor when doing the auto tune.




Click Start Tune. You may get some feedback from the algorithm asking that you make adjustments to things like speed. When the command completes you will get some feedback such as that shown below.




After an initial success you may wish to run it for a longer Travel Limit. Then use Motion Direct Commands to jog and make sure the motor seems to function properly (no high pitch or any such thing).


Axis properties has a Gains tab for adjustments.



The **Output tab** can also be helpful. Sometimes, depending on the application, adjustments to torque force scaling can be helpful in obtaining a certain response.




On the Gains tab click Manual Adjust to access a dialog which allows you to change gains while the motor is running. Same for Torque Force Scaling on the outputs tab. You can also add filtering.




Systems that use CIP-Motion protocol often are easier to tune when you have Notch Filter Frequency enabled on the outputs tab.

The commands below allow you to run an auto tune and then apply the results from the ladder logic. These functions use the parameters you have in the system already (such as those discussed above).




You can use a SSV to acquire or adjust specific values associated with tuning such as the example below.




Lecture 16: Tuning an S-Curve Movement from an Instruction


How to set up a trend for tuning an S-curve. Systems with a large inertia may do better with an S-curve type acceleration. So the question is, how do we determine when the system is responding smoothly.

Start with a trend with the following parameters: .ActualPosition, .AverageVelocity, .TorqueFeedback. Note that TorqueFeedback is one of the parameters that will not appear in the list of parameters that can be plotted unless you have entered (requested) it in the Properties dialog under the Drive/Motor tab in the Real Time Axis Information area.



Below plot shows the S characteristic.





The “S” shows up in position but it shows up much more strongly in velocity. The activity of changing position with an S-curve is strongly indicated in the velocity curve. The Jerk value in the MAM command as well as the accel decel rates modifies the curve. In the below case we went from 50 to 100 Jerk and then down to 10.



The tradeoff is how long it takes a maneuver to complete as opposed to how smooth the transition is.

NOTE THAT ACCEL AND DECEL JERK VALUES DO NOT APPLY WHEN USING TRAPAZIODE.

However it **is** affected by accel/decel rates.

Lecture 17: Servo Acceleration Explained



This chapter clears up a few items from previous section.

Lecture 18: Servo S-Curve Jerks Explained


This lecture points out the difference between a S-Curve and a Trapizoid.

Lecture 19: Using the Conversion Constants Calculate Tool


What are we referring to when we speak of conversion constants? **Drive Resolution** under the Drive/Motor tab, **Conversion Constant** and **Position Unwind** under the Conversion tab. The values will always be dependent on the application. The tool we are going to examine can be helpful for determining these values.




You must be **OFF LINE** to use this tool. On the Drive/Motor tab click on the **Calculate** button. This will bring up a dialog called **Calculate Position Parameters** (next page).



The units will match what you have configured for your application. Fill in the text boxes according to your applications needs and click on Calculate [? Update ?]. In the above example we want to move 120 mm per motor revolution. The tool calculates the three values we will have to enter into the setting on the two tabs shown on the previous page. This also applies to **gear boxes**, if we had a 3:1 gear box on our shaft in the above example we would enter the number 3 in the “per Motor Rev” text field (see below).




Another use is for calculating the Position Unwind value. Let's start with a 1:1 ratio...




Now we want our shaft to rotate 360 degrees (rollover). Now click calculate.



Now download this modified application and run... The shaft is going to turn 360 degrees. To do this access the Motion Direct Commands feature from the motion group Axis01. First issue the Reset Faults command (MAFR).



Now issue MSO for custom motor on (the motor will turn on). Next issue MAH for motion axis home. Then issue MSF for Motion Axis Off. Fill out the information as shown below. We want position at 360 and speed at 5. (the order of commands that worked was Motion Axis Home, Motion Servo On, enter parameters, Execute).



You can monitor the move in the tag display.

			0	Decimal
Axis01.AccelStatus			-28.333332	Float
Axis01.ActualAcceleration			86.42467	Float
Axis01.ActualPosition			4.987	Float
Axis01.ActualVelocity				

Another example, **Belt Drive**. You want the belt to run 500 mm and you have a 10:1 gear box. So **one revolution of the drive will produce 10 revolutions of the GB**. Putting the 10 in the “per Motor Rev.” field allows the application to take the GB into account when you click the calculate button. In the end, **10 turns of the GB output will produce 500 mm of movement**. Servo Motion One (first course) may have some equations that will help here.

Note: if you are using a linear drive you will not get the lower text boxes in the calculate dialog (the unwind terms).

Unwind means that after moving for x units, the position is back to the starting point. For example, a servo is turning a wheel on a car. After traveling 360 degrees, it is back to where it started.

20. Understand a Simple Mechanical Drive System and Convert

Here we will look at conversion constants a little more. The below table is from course one. This is basically doing what the calculator does.

Here is an Rotary Axis example:

How to calculate conversion constants

A gearbox of 3:1 ratio used

I

Pulley attached to the gearbox output is 48:40

The drive constants are set to 1,000,000 Cts/Motor rev

(1,000,000 Counts/Motor Rev) (3) (48)

$$\text{Conv Constant} = \frac{\text{-----}}{(40)} = 3,600,000 \text{ Counts per Unit}$$

whatever the units are set to....this example does not note the units....but if you need to reference something then says the units are a small box so:

3,600,000 counts per box

So in the servo's attributes tab under Conversions:

Conversion Constant: 3600000 Counts per box based on 1000000 counts per motor rev

Position Unwind: 3600000 Drive counts per Unwind based on 1000000 counts per motor rev


So the units being measured are a box, in this case the system is calculated to one box equals 3,600,000 counts

Note: just as the numerator is (3 GB)(48 Pully) the denominator is likely (1 GB)(40 Pully).


The equation is:


(Counts/Motor Rev)*(left side of GB * left side of Pully) / (right side of GB * right side of Pully)

21. The Difference Between Linear Cams and Cubic Cams




The Cam1Profile parameter reserved space for 40 points but the profile below only uses 12.






Below we have changed the TYPE of cam from Linear to Cubic. You can see it smooths it out for us. Much more practical.




22. Using a Servo Cam Editor

Make sure you are offline or you could invoke unexpected movement.



Specifying the Cam Profile

To execute a MATC instruction, a calculated Cam Profile data array tag must be specified. Cam Profile array tags may be created by the RSLogix 5000 tag editor or the MATC instruction using the built-in Cam Profile Editor, or by executing an Motion Calculate Cam Profile (MCCP) instruction on an existing Cam array.




The data within the Cam Profile array can be modified at compile time using the Cam Profile Editor, or at run-time with the Motion Calculate Cam Profile (MCCP) instruction. In the case of run-time changes, a Cam array must be created in order to use the MCCP instruction.



All but the status and type elements of the Cam Profile array element structure are "hidden" from the RSLogix 5000 tag editor. These hidden elements are of no value. The status parameter is used to indicate that the Cam Profile array element has been calculated. If execution of a camming instruction is attempted with any uncalculated elements in a cam profile, the instruction errors. The type parameter determines the type of interpolation applied between this cam array element and the next cam element.


24. Motion Axis Time Cam Instruction Intro

Begin by making a new controller application.



From the Motion Move tab select and add to program the Motion Axis Time Cam function block. Now add a motion group, we will call it ServoMastering. This is a virtual axis, name the tag VirtualAxis_01. In the controller properties Date/Time tab select Enable Time Synchronization, this allows the motion group to run properly. We will run with the below values.





[Note: CAM Profile tag must be an array.]

At this point we have made an axis, now we want to make the motion control. The “control” is just the tag name we give it. This value goes in the Motion Control field of the function block. Keep in mind the HELP system is an excellent reference for filling out the function block.

.EN – set when rung goes true, stays set until rung goes false.


.DN – set when the axis time cam instruction is successfully initiated, not when the movement is complete.

.ER – indicates when the instruction detects an error, such as if the axis is not configured. (examine error code).

.IP – *in process* bit set on positive rung transition and cleared when terminated.

.PC – *process complete* is cleared on positive rung transition and set in Once Execution Mode when the time leaves the time range defined by the current active cam profile.


Refer to troubleshooting techniques discussed in course one. Error code explanations can be found in help file under topic Motion Error Codes (.ERR). Refer to HELP file for a discussion on cam topics such as **Camming Direction**, **Camming in the Same/Opposite Direction**, **Changing the Cam Profile**, **Changing the Camming Direction**, and **Specifying the Cam Profile**.



The above figure illustrates the order of operations. We will discuss MCCP coming up.


Now we will look at how to turn the axis on. The only way to do this with a virtual axis is to use the homing command, MAH. ServoActionStatus means the servo is on (first course). Now we want to start the cams.

You also want to stop the servo (MAS), do not leave the bit on. There are different types of stop. Here we will use Time Cam. Note that there could be other motion going on in the system so we have to select carefully.




Now we want to create a cam profile and associate it with our MATC block. We are replacing the function MATC Cam Profile entry (started out as CAMProfile) with the first instance of that profile. Remember, CAMProfile is a control array. (I think he means replace CAMProfile with first element of CAMProfile control array CAMProfile[0].)



Now we open the cam editor and enter our cam profile (click Apply).





Put the emulator in RUN mode. Toggle HMI_ServoSystem_On tag and then set HMI_CamStart to on. Next run the trend. We had the cam set to run once as opposed to continuous.



Now we are going to add a contact closure with the cam tag MATC_01.IP (in process). Toggle HMI_CamStart on/off and then set MATC_01.IP on (?). Now open the trend. We see that the cam cycles, runs continuously. We can adjust the distance scaling, try 100 and notice that the velocity has to increase to keep up with the cam timing.




Now create a trend on the position and velocity parameters. Then download to the emulator. Make sure it is running.




The time cam describes the distance you want to travel in the amount of time you want the move to take.

25. Breakdown the Difference Between an Immediate and Pending MATC Use

This topic falls under time cams. It is a different scenario. We have a small state machine with a time cam which itself runs another time cam twice. On our MATC function block (one of them) we see the parameter Execution Schedule set to pending (this is the second, the one that runs twice). This allows us to use the .TimeCamPendingStatus tag as a counter. At the last rung “it” is reset to another sequence. The program being used here is Timing_CAMs in TimingCAMs.ACD (exported as a graphic in same directory as SMM2).




Sequence (blue) runs four times, waits 4 seconds, re-homes,




Then in a lower rung it runs the first cam ...



Next it runs the pending cam twice ...




And concludes with ...



The idea here is to notice the difference between pending and immediate and how they affect the outputs.

26. MATC Logic Used with a Virtual Axis With Trouble Shooting




In this lecture we will be discussing this key area of code.




Type	AXIS_SERVO_DRIVE
Description	Faulted
Axis State	MotionAxis_1
Drive Name	10
Axis Fault	PhysicalAxisFault
Drive Fault	PositionErrorFault
Module Faults	No Faults
Attribute Error	No Faults

To begin we start the application using the HMI_System_On tag. We are using the hardware application (not emulator) at the moment so we can create a fault by changing the MATC Distance Scaling parameter to 50 causing the motor to have to move too fast to keep up with the cam. This is a position error fault. **A position error means you have tried to do something the servo is not capable of.**



In this case we have set really tight limits (figure to left).

If you are wondering if the error is with something like the limits or with the motor, amp, or cable you can reset and try jogging the motor. If it works you know those things are okay.



Next we will try increasing the position error tolerance to 10.xxx, reset the fault, and run. It does run and does not generate a fault.

Make sure you try this type of troubleshooting before changing out the motor.

The errors we had on the last page while running the hardware will not appear when we do the same thing on the virtual axis. The virtual axis does not have those position error tolerances associated with it because there is no hardware.

When using a MATC cam you are basically specifying a length of time and a distance to cover in that timeframe. The software will drive the motor to the required speed. Be aware of the physical aspects of the settings you enter. And keep in mind the virtual axis will not generate many of the faults that the hardware will.


27. MATC Scaling Explained To Limit Confusion

Do not issue a command unless .ServoActionStatus is ON, otherwise your MATC would generate an error.



In above graphic, by default, both the time and distance scaling parameters are set to 1. To scale a time cam profile enter a Time Scaling or Distance Scaling value other than 1. Increasing the time scaling value of a cam profile decreases the velocities and accelerations of the profile. To maintain the velocities and accelerations of the scaled profile approximately equal to those of the unscaled profile, the Time Scaling and Distance Scaling values should be equal. For example, if the Distance Scaling value of a profile is 2 then the Time Scaling value should also be 2 to maintain approximately equal velocities and accelerations during execution of the scaled time cam. Important: decreasing the Time Scaling value or increasing the Distance Scaling of a time cam increases the required velocities and accelerations of the profile. This can cause a motion fault if the capabilities of the drive are exceeded.

Before we run lets review what transpires in this cam profile. Keep in mind this is a time cam. When a cam profile is specified in a MATC instruction the Master Coordinate Value defined by the profile array takes on time units in seconds and the slave units are the slave values which take on the units of the slave servo. Contrast this to the fact that the time and distance scaling parameters are unitless, the values are basically used as multipliers to the cam profile. So the cam profile is relevant but at the same time the distance and time are more or less multipliers. This is what controls the velocity of the servo. The same is true for the speed and acceleration. So say we



have a distance of 10 and a time of 1, what will happen? Toggle HMI_StartCam. We have the execution mode set to zero so it will run one time. Likewise, having execution mode set to continuous (1) will run the cam multiple times.




Figure 2 one possible cam start logic.

MATC bits


- .EN – set when rung goes true, stays set until rung goes false.
- .DN – set when the axis time cam successfully **initiated**.
- .ER – indicates when the instruction detects an error.
- .IP – **in process** bit set on positive rung transition.
- .PC – **process complete** is cleared on positive rung transition.


28. MATC Instruction With A Natural Move Command



In this lecture we will add a ‘rolling time change’ to our time cam. We will add a couple of compute statements, one will be **ProductPerMinTime** (REAL) and the other **MachineSpeed** (DINT). We multiply MachineSpeed by 60 since we are working in seconds. Parameter **MovementTimeScale** will be REAL.

So now MotionMovementTime is used in the MATC block in the TimeScaling field. We call this a rolling system. And we initialize MachineSpeed at 250 (items per minute). You can try changing the distance, this will change the velocity of the servo motor.





By default, both the Time and Distance Scaling parameters are set to 1. To scale a time cam profile, enter a Time Scaling or Distance Scaling value other than 1.

Increasing the Time Scaling value of a cam profile decreases the velocities and accelerations of the profile, while increasing the Distance Scaling value increases the velocities and accelerations of the profile. To maintain the velocities and accelerations of the scaled profile approximately equal to those of the unscaled profile, the Time Scaling and Distance Scaling values should be equal. For example, if the Distance Scaling value of a profile is 2, the Time Scaling value should also be 2 to maintain approximately equal velocities and accelerations during execution of the scaled time cam.

Important:

Decreasing the Time Scaling value or increasing the Distance Scaling of a time cam increases the required velocities and accelerations of the profile. This can cause a motion fault if the capabilities of the drive system are exceeded

SimpleMATC_WithMove.ACD

29. Servo Motion Mastery PCAM Intro

The topics of this lecture are the basics of a **position cam** and how to calculate a position cam. Here we are using the phase manager.






Figure 3 elements of a phased system.




Figure 4 position cam Motion Calculate Cam Profile function block.




Slave axis, in blue, is running relative to the master in red. Note we are plotting velocity.




The MCCP cam being implemented, start and end slopes are both 1.87403 (on Motion Calculate Cam Profile [MCCP] function block, not cam table). This cam profile will be used by the Motion Axis Position Cam (MAPC) function block (not clear why they are not on separate states with MCCP coming first).




First and foremost, the program calculates the cam using the MCCP block and that information will be used by the MAPC block. Click the ellipse in the MCCP block beside CAM / RunCam and the Cam Editor appears (shown above). **Note the Start Slope and End Slope entries** at MCCP cam profile above. Now in the MAPC block click the ellipse beside the CamProfile / StartProfile[0] entry to see the cam profile below.





As soon as the position cam indexes and the IP bit goes true it will transition to the next state. The code is set up so no move may be in progress, CAM calc must be complete, and the move begins. Implies that MCCP fires off MAPC. Need to know the link between MCCP and MAPC, they do not seem to access the same "profile" arrays. Consider the code at states 20 and beyond below. The trend shows the result.




This is rung 5, state 20.





So the IP and SEGMENT terms are what is used to transition. This code oscillates between states 20 and 30. MPAC1.SEGMENT toggles as well. The trend plot on next page shows velocities and positions.



Here we are looking at velocity only, this can help us identify errors or areas in need of improvement.



The timing of the servos is really the key to the system. Also **consider the course rate update of the master (axis) group as it plays a role in the calculations**. Find this value in the properties of motion group MT1. In this case we are using 2 ms. (We are running virtual axis).




Timing and Course Update Rate are the keys to servo motion systems, examine them carefully.



Note that it is not necessary to use the MCCP block, you can run MAPC with a hard coded cam (see below). This method is used when you have to adjust CAMs on the fly. See lessons below for more on this topic.


30. Servo Mastery PCAM Explained In Detail

At this point we have moved the code above (ch 29) into a program without the phase structure. Here we are still using a virtual axis running a motion axis position cam (MAPC). In this module we will examine what have done above at a slower pace. In lecture 31 below we will build a program from scratch, make a position cam, use the position cam (using real hardware, not emulator). This is a simplified system. Now let's look at the cam used in MACP, ellipse button associated with cam profile.



In this case Axis1(the slave) is linear and the Conveyor is a rotary (cubic?). Master axis is moving from zero to thirty and the cam is controlling the slave axis to the blue line (slave is following the master). So we can see that the position of the master axis determines the position of the slave axis by means of the table. Now we are going to use the Motion Axis Move command to move to position 50 at a speed of 1 (slowly). We should see the shape of the cam represented on the trend. Light color is master (running), blue is the slave (following). Green is the velocity. So we see that the blue line in the trend resembles the cam profile. As the master goes from 0 to 30 (in this case) it will the slave axis (axis1) will follow according to the blue line in the cam profile. The position trend should look like the blue cam line. In this first example we tell the master (conveyor) to run to position 50, but the slave (axis1) is only programmed (cammed) to follow to 30. So it will stay in place as master goes above 30.








This is a second run where we increased the speed of the conveyor. We can see that the cam caused the speed of the slave (axis1) to greatly increase so it can keep up. The velocity lines are sharper.

31. Building a PCAM From Scratch


In this lecture we will build an application with a cam from scratch. The name is **ServoAxis_PositionCam**. We will create a periodic task so that we can better time the system.



In this case we will create a periodic task, this allows us to better time the system, particularly in this example.




Next we add some IO as you see in this graphic.




Next create a motion group.




Now create the servo drive, call it Pusher. This is a physical drive [AXIS_SERVO_DRIVE].




Now create a virtual drive called Conveyor.




An important step, go to controller properties Date/Time tab and enable time synchronization as shown below.




Now go to the Pusher axis properties and give it an associated module, the one down in the hardware IO list (Kinetic_6000).




Now go to the Drive/Motor tab and select a motor.




Also select the Real Time Axis Information attributes, in this case we will use Position Error and Velocity Feedback. In this case we do not want to use Drive Enable Input Checking so **uncheck** it.



Below is the value of the conversion constant we will use in the Pusher case. Recall that the value of the conversion factor is determined, to some extent, by the application.




Now we do the same for the **Conveyor**. Select positioning mode Rotary and enter 36000 for Position Unwind. This means the axis values will reset after each 360 degree rotation. Use 10000 for conversion constant.




Position unwind is 10,000 feedback counts/1 position units times 360 degrees for the axis to return to the “home” position. This equals 3.6M.


Now go to the dynamics tab of the Conveyor properties dialog. We have to enter values for the various max and min setting. Since this is a virtual drive the values entered do not have to be realistic (like those shown below).




Now click both Calculate buttons and make an entry on the slider and then click OK.




These calculations are based on the max and min values we entered. This will modify the values we had entered.




Now open the Main Routine so we can create some ladder logic. Go to the Motion State tab to select the motion function blocks.







We will want to create Home and an On rungs.



Where ...



We want to add some NC rungs in front of our homing function blocks (MAH) so we do not re-home an already homed axis. There are several tags that can do this, a good one might be Conveyor.HomedStatus (same for pusher). But the simplest way is to use a one shot. Note that our one shot is declared as SystemONS with data type BOOL and is a control array of 1 dimension (next page).




Now we write a rung to test the .PC bit



(.ProcessComplete) to make sure both have come on and have completed homing. Then we want to check the .ServoActionStatus bit to be sure they report active. If all are true we can start the cam.




Where HMI_CamStart is a BOOL. Now add a one shot and a position cam function block, MAPC.



Create these other parameters...



Now we have ...



At this point we can review the help file for some details...

The function block is filled out below.

Motion Axis Position Cam (MAPC)

The Motion Axis Position Cam (MAPC) instruction provides electronic camming between any two axes according to the specified Cam Profile.

When executed, the specified Slave Axis is synchronized to the designated Master Axis using a position Cam Profile established by the RSLogix 5000 Cam Profile Editor, or by a previously executed Motion Calculate Cam Profile (MCCP) instruction. The direction of Slave Axis motion relative to the Master Axis is defined by a flexible Direction input parameter. The camming Direction, as applied to the slave, may be explicitly set as the Same or Opposite or set relative to the current camming direction as Reverse or Unchanged.


To accurately synchronize the slave axis position to master axis position, an Execution Schedule setting and an associated Master Lock Position can be specified for the master axis. When the master axis travels past the Master Lock Position in the direction specified by the Execution Schedule parameter, the slave axis is locked to the master axis position according to the specified Cam Profile beginning at the Cam Lock Position.

The cam profile can also be configured via the Execution Schedule parameter to execute Immediately or Pending completion of a currently executing position cam profile. The cam profile can also be executed Once or Continuously by specifying the desired Execution Mode. The Master Reference selection allows camming input from the master to be derived from either the Actual or Command position of the Master Axis.

To support applications which require unidirectional motion, a "slip clutch" feature is available, which prevents the slave from "backing-up" when the master axis reverses direction. This feature is controlled by the Master Direction parameter. Master and Slave Scaling functionality can be used to scale slave motion based on a standard cam profile without having to create a new cam table and calculate a new cam profile.

Operands

Ladder Diagram





Operand	Type	Format	Description
Slave Axis	AXIS_CIP_DRIVE AXIS_VIRTUAL AXIS_GENERIC AXIS_SERVO AXIS_SERVO_DRIVE	Tag	The name of the axis that the cam profile is applied to. Ellipsis launches Axis Properties dialog.
Master Axis	AXIS_CIP_DRIVE AXIS_FEEDBACK AXIS_CONSUMED AXIS_VIRTUAL AXIS_GENERIC AXIS_SERVO AXIS_SERVO_DRIVE	Tag	The axis that the slave axis follows according to the cam profile. Ellipsis launches Axis Properties dialog. If Pending is selected as the Execution Schedule, then Master Axis is ignored.
Motion Control	MOTION_INSTRUCTION	Tag	Structure used to access block status parameters.
Direction	UINT32	Immediate or Tag	<p>Relative direction of the slave axis to the master axis:</p> <ul style="list-style-type: none"> Same – the slave axis position values are in the same sense as the master's Opposite – the slave axis position values are in the opposite sense of the master's. <p>Or relative to the current or previous camming direction:</p> <ul style="list-style-type: none"> Reverse – the current or previous direction of the position cam is reversed on execution. When executed for the first time with Reverse selected, the control defaults the direction to Opposite. Unchanged – this allows other cam parameters to be changed without altering the current or previous camming direction. When executed for the first time with Unchanged selected, the control defaults the direction to Same.
Cam Profile	CAM_PROFILE	Array	Tag name of the calculated cam profile array used to establish the master/slave position relationship. Only the zero array element ([0]) is allowed for the Cam Profile array. Ellipsis launches Cam Profile Editor.
Slave Scaling	REAL	Immediate or Tag	Scales the total distance covered by the slave axis through the cam profile.
Master Scaling	REAL	Immediate or Tag	Scales the total distance covered by the master axis through the cam profile.
Execution Mode	UINT	Immediate	<p>Determines if the cam profile is executed only one time or repeatedly:</p> <p>0 = Once – cam motion of slave axis starts only when the master axis moves into the range defined by the start and end points of the cam profile. When the master axis moves beyond the defined range cam motion on the slave axis stops and the Process Complete bit is set. Slave motion does not resume if the master axis moves back into the cam profile range.</p> <p>1 = Continuous – Once started the cam profile is executed indefinitely. This</p>

			<p>feature is useful in rotary applications where it is necessary that the cam position run continuously in a rotary or reciprocating fashion.</p> <p>2 = Persistent - When the Master Axis moves beyond the defined range, cam motion on the Slave Axis stops and the PositionCamLockStatus bit is cleared. Slave motion resumes in the opposite direction when the Master Axis reverses and moves back into the cam profile range, at which time the PositionCamLockStatus bit is set.</p>
Execution Schedule	UINT32	Immediate	<p>Selects the method used to execute the cam profile. Options are:</p> <p>0 = Immediate - The slave axis is immediately locked to the master axis and the position camming process begins.</p>
Execution Schedule	UINT32	Immediate	<p>Selects the method used to execute the cam profile. Options are:</p> <p>0 = Immediate - The slave axis is immediately locked to the master axis and the position camming process begins.</p> <p>1 = Pending - lets you blend a new position cam execution after an in process position cam is finished. When Pending is selected the following parameters are ignored: Master Axis, Master Lock Position, and Master Reference.</p> <p>2 = Forward only - the cam profile starts when the master position crosses the Master Lock Position in the forward direction.</p> <p>3 = Reverse only - the cam profile starts when the master position crosses the Master Lock Position in the reverse direction.</p> <p>4 = Bi-directional - the cam profile starts when the master position crosses the Master Lock Position in either direction.</p>
Master Lock Position	REAL	Immediate or Tag	<p>When the Master Offset = 0.0, the Master Lock Position is the Master axis absolute position where the slave axis locks to the master axis. If the Master Offset is X, then the Slave axis will lock to the Master axis at the absolute master position value of Master Lock Position -X.</p> <p>For example: Assume a Master Lock Position = 50 and a Master Offset Move = 10. Also assume that the Master axis move (MAM) and Master offset move (MOM) start at the same time. Then the Slave will lock to the Master at an absolute Master axis position of 40. This in effect shifts the Cam profile 10 units to the left.</p> <p>If Pending is selected as the Execution Schedule value, then Master Lock Position is ignored.</p>
Cam Lock Position	REAL	Immediate or Tag	This determines the starting location in the cam profile.
Master Reference	UINT32	Immediate	<p>Sets the master position reference to either Command position or Actual position. If Pending is selected for the Execution Schedule value, then Master Reference is ignored.</p> <p>0 = Actual - slave axis motion is generated from the current position of the master axis as measured by its encoder or other feedback device.</p> <p>1 = Command - slave axis motion is generated from the desired or commanded position of the master axis.</p>
Master Direction	UINT32	Immediate	<p>This determines the direction of the master axis that generates slave motion according to the cam profile.</p> <p>Options are:</p> <p>0 = Bi-directional - slave axis can track the master axis in either direction.</p>



So now we need to put in a cam profile. The cam profile needs to have depth, we have to make space for the number of instances we plan to use. In this case we'll use 100.

Data Types:

CAM_PROFILE[100]




Select the initial element in the MAPC_Cam Profile entry.




We could open the cam editor and type the points in manually, but it can also be done through Excel using the cell drag tool. You can paste into a blank cam table. Start by using the cubic cam. Next create a rung to run the cam. In this case we will use Motion Axis Move (MAM). We are going to run the master cam which is the conveyor. Notice MAPC Cam Profile, the array has 100 members but you always reference the first position (zero) in this position (naming field).

To	Use This Move Type	And Enter
Move an axis to an absolute position	Absolute	0
Move an axis a specified distance from where it is now	Incremental	1
Move a Rotary axis to an absolute position in the shortest direction regardless of its current position	Rotary Shortest Path	2
Move a Rotary axis to an absolute position in the positive direction regardless of its current position	Rotary Positive	3
Move a Rotary axis to an absolute position in the negative direction regardless of its current position	Rotary Negative	4
Offset the master value of a position cam to an absolute position	Absolute Master Offset	5
Offset the master value of a position cam by an incremental distance	Incremental Master Offset	6
See Choose a Move Type for a Rotary Axis below for more information about rotary moves.		

The move type help file can be useful.







	{...}
- SystemMAPC	0
SystemMAPC.AC	0
SystemMAPC.ACCEL	0
SystemMAPC.CalculatedDataAvailable	0
SystemMAPC.DECEL	0
SystemMAPC.DN	1
SystemMAPC.EN	0
SystemMAPC.ER	0
+ SystemMAPC.ERR	0
+ SystemMAPC.EXERR	0
+ SystemMAPC.FLAGS	637534208
SystemMAPC.IP	1
SystemMAPC.PC	0
+ SystemMAPC.SEGMENT	0
+ SystemMAPC.STATE	0
+ SystemMAPC.STATUS	0
SystemMAPC.TrackingMaster	0


What to do if you have an error or fault? Right click on the Motion Control Entry in MAPC and click on Monitor "SystemMAPC" which will take you to the tag values. Look up your error code in the help file.

This is a test run of our first cam.







Now we have edited the cam so it more closely resembles a pusher.



Now we have modified the cam to take out some of the spikes.



The video shows a version of the code where the master axis is reset once it hits 40 so the process repeats.




32. MAPC Common Issue With Master Reference

In this lecture we will be discussing position cams. **There is a known problem with position cams.** This problem does occur in systems where the master cam is virtual. Say you are running a master cam and there is a physical motor connected. Using a Master Reference = Actual gives the system a more refined movement as opposed to Virtual.

Say you are in a situation where the motor is trying to hold itself in position and the cam profile senses that movement. So the IP bit of the Motion Axis Position Cam will trigger from IP (In Progress) to PC (Process Complete). It does this because it senses the movement.

If you have that problem it is a simple matter to **change from Master Reference = Actual to Command** and you will not have the problem. My guess is he means that in command mode the system waits for a command as opposed to monitoring physical movement and acting on that.

Also, any movement in the negative direction will cause the MAPC to transition from In Progress to Process Complete. This is a bug that RW knows about.



33. MAPC PC Bit explained

Here we are going to look further into the MAPC transition from IP to PC. "... as soon as the master axis goes out of the cam we see the transition from IP to PC." What he means is if we try to access a table point outside of our points. If we have a table with 10 rows and the program tries to access point 11, outside the table, it will transition in this way, from IP to PC. (which it should it would seem?)

34. MAPC Adding Common Health Checks


We have a servo and we want to turn it on, but we do not want to turn it on if it is already running. And we also want to make sure it is healthy before we start it. We can **use the GSV function block with Class Name: Module, Instance Name: Kinetic_6000, Attribute Name: FaultCode, and Destination Tag: ServoController_FaultCode.** Check the destination tag and if it is not equal to zero we know we have a fault.

GSV
Get System Value
Class Name Module
Instance Name Kinetix_6000
Attribute Name FaultCode
Dest ServoController_FaultCode
0



GSV
Get System Value
Class Name Module
Instance Name Sercos
Attribute Name FaultCode
Dest Sercos_FaultCode
64776








So we can now check for the conditions and take proper action. [IF NOT FAULTED PROCEED]

35. Use scaling in an MAPC instruction

The MAPC has master and slave scaling features. We want to look at how these values effect the servos motion.



As we might expect, changing the scale factor has a corresponding effect on the amplitude of the movement.



The way this works:

- making adjustments to the **cycle time** is done by changing the master scaling factor.
- Making adjustments to the **amplitude** is done by scaling the slave.

36. MAPC Cam Lock Position Function Talk - Not program and Show

Not much, kind of just babbling.

37. MAPC Master Lock Position Function - Not program and Show

Two points that are often times missed include **Master Lock Position** and **Cam Lock Position**. If the master axis is greater than the master lock position then it is not going to ‘pick-up’ until the next time the master axis is actually below that mark.

From Shane: Say the master axis is stopped at position 6 mm and the Master Lock Position is set at 5 mm and the cam is started at 5.5 mm. Then the cam profile (also known as the slave) would not (start?) until the master axis was below the master lock position.

Another example:

```
Untitled - Notepad
File Edit Format View Help
Master Axis is stopped position 6mm
Starts after 6mm moving forward.

The instruction or cam profile will not lock until
the master axis reaches a position of 5mm as stated by the
master lock position.

Master Lock Position 5mm

Cam started at 5.5mm

Then the cam profile or in other words the slave servo would not until
the master axis was below the master lock position.

Axis position .0032 and slightly moving not at perfect zero .00000
```

Untitled - Notepad

File Edit Format View Help

If the MAPC instruction is in an .IP state then no worries but if the MAPC instruction is not in a .IP state then the slave will run until the master reaches the master lock position.

-Master Axis is stopped position 6mm
Starts after 6mm moving forward.

The instruction or cam profile will not lock until the master axis reaches a position of 5mm as stated by the master lock position.

-Master Lock Position 5mm

-Cam started at 5.5mm (Start running the slave servo)

Then the cam profile or in other words the slave servo would not until the master axis was below the master lock position.

Axis position .0032 and slightly moving not at perfect zero .00000

38. Difference In A MAPC and a MATC

Here we will discuss the differences between a time cam and a position cam.

First the **position cam**. We've spoken of how the IP and PC bits work, they are position based on the master, master and slave coincide based on position. It boils down to understanding the **master reference**, whether it is set for **actual** or **command**. Meaning, is it the **actual** value of the encoder coming back or is it the **commanded** value that the master is being told to do? Using the position of the master to control the slave, operating based on another servo (the master). (seems like actual would be the way to go)

Now the **time cam**. In this case it is the time which it takes to do something. If you look at the distance the servo has to travel and the amount of time it has to travel that distance, these two constraints are used to determine the acceleration and decelleration as well as the velocity of the servo. You are doing something in a set time frame.

If you are the only controller controlling the servos (**master**) then you need to **enable time synchronization**.



If your controller is a slave to another controller you do not need to enable time synchronization, you need your controller to be time synchronous with the other controller.

39. Starting from Scratch


Here we begin a series of lectures on MAPC camming and how to **blend cams together**. We will work with a physical axis (Axis01) and a virtual axis. The name of this program is **Servo_Blending_Example.acd**.

Servo_Blending_Example [1756-L73 30.11]*


To begin we will add a routine which will represent the virtual axis.




Notice below that we want to add a contact from the virtual axis so we use the drop down to access the virtual axis, do not confuse with the code module VirtualAxis. Also, when you create a virtual axis a lot of tags are generated.



This rung will never execute due to the AFI statement. The purpose of the rung is to display the virtual axis average velocity and actual position so the programmer can see it. The .ServoActionStatus tag will only be true when the virtual axis is running. Note, it is usually better to monitor average velocity.



Next we configure a rung for jogging.




Now a command to stop the axis when we are not jogging.




40. Setting up the Physical Axis

Now we are ready to start the programming for Axis01. First we add a new code module Axis01_MAPC_Controls.




- ServoState	{ ... }
+ Servo State[0]	0
+ Servo State[1]	1
+ Servo State[2]	2
+ Servo State[3]	3
+ Servo State[4]	4
+ Servo State[5]	5
+ Servo State[6]	6
+ Servo State[7]	7
+ Servo State[8]	8
+ Servo State[9]	9

Rough out of the program so far: make sure axis is off, clear any faults, perform a shutdown reset, turn servo on.




41. Adding elements for the state controls

Now we are going to add some controls to the state machine. To start we want to monitor our motion group. We will add a tag to the code that describes the motion group. **This particular tag lets us check that the group is synchronized**. This lets us know that the group is ready to operate and running the functions that follow will not cause a fault.




This next tag lets us check that the instruction actually did happen. To do this we check the Done bit.




Now we would like a more robust method of resetting our state machine to zero, we do not want to depend only on the first scan rung so we are going to augment that rung. We will add a CLR (clear) function block. So now there are two possible ways of resetting the state machine, the first is the first scan function, the second is if a shutdown happens or if a fault happens. Under these conditions we would want to stop control and stop motion. So our first rung now looks like this.




Next, in the below group, we want to make sure that we are only resetting one at a time. The group currently looks like this...




Now we are going to say, if it is faulted we will reset the fault only and if it is shut down, we will only activate the Motion Axis Shutdown function. Notice that if it is a shutdown **we only want to activate the Motion Axis Shutdown Reset if we are not faulted**. So we add the EQU statement to check for a zero in the fault register. It would actually be rare that a fault and shutdown happen at the same time. Our code block now looks like this...




We are also going to add a tag on rung 3 which ensures that the motion group is synced before we turn on the servo and advance to the next group.




We have also added a ladder to rung 1 which forces the ServoState[3] to 2 when the Axis01_OnPB is not being pressed.



Another tag is added to ensure that if the Axis01_.ServoActionStatus is on we can cut it back off.





Application to this point.




42. Adding our first MAPC

We add a new state at the bottom and add a new tag.

We begin with MAPC, the slave axis is Axis01, the master axis is Virtual_Axis, we will call it MAPCMotion_Control and give it a dimension of 3 as we will need several.





Below the help file for Direction is listed. We will use Same. Next we will have to create a cam profile, we will declare the tag MAPC_CamProfileONE. The remaining entries are shown in the graphic below.


(Direction)	UINT32	UINT32	Immediate or Tag	Relative direction of the slave axis to the master axis: <ul style="list-style-type: none"> Same - the slave axis position values are in the same sense as the master's. Opposite - the slave axis position values are in the opposite sense of the master's. Or relative to the current or previous camming direction: Reverse - the current or previous direction of the position cam is reversed on execution. When executed for the first time with Reverse selected, the control defaults the direction to Opposite. Unchanged - this allows other cam parameters to be changed without altering the current or previous camming direction. When executed for the first time with Unchanged selected, the control defaults the direction to Same.
-------------	--------	--------	------------------	--

New Tag

Name:	MAPC_CamProfileONE	<input type="button" value="Save"/>
Usage:	<controller>	
Type:	Base	Connection...
Alias For:		
Data Type:	CAM_PROFILE[30]	[...]
Parameter Connection:		
Scope:	Servo_Blending_Example	
External Access:	Read/Write	
Style:		
<input type="checkbox"/> Constant		


MAPC	Motion Axis Position Cam	(EN)
Slave Axis	Axis01	(DN)
Master Axis	Virtual_Axis	(ER)
Motion Control	MAPCMotion_Control[0]	(IP)
Direction	0	(PC)
Cam Profile	MAPC_CamProfileONE	
Slave Scaling	1	
Master Scaling	1	
Execution Mode	Once	
Execution Schedule	Immediate	
Master Lock Position	0	
Cam Lock Position	0	
Master Reference	Command	
Master Direction	Forward Only	

Next we will build up the cam profile. Below is our first draft. Note the velocity (red line) is kind of extreme.



We have also added a ladder to get us to the next state. The rung we are adding executes the MACP block but then immediately goes to state 4. To run, remove Axis01.ServoActionStatus at rung 1 and toggle


Servo_Axis01_SystemStart also on rung 1. Click  to compile.



Now go up to rung 1 and toggle Servo_Axis01_SystemStart to run the cam.

We will want to monitor some tags like average velocity, we want average virtual velocity greater than 0 (use "1" in GRT block) before we execute the Motion Axis Position Cam (MAPC) instruction. This code modification is shown on the next page. Again, this greater than instruction is ensuring the virtual axis is on and moving before we execute the MAPC instruction.


In this case the virtual axis is the master which Axis01 will follow according to the entries in the slave column.




Note that we need to verify that the virtual axis is actually on. To do this we can monitor the velocity of the virtual axis. We can view the virtual axis code in the VirtualAxis module.



Before we turn on the MAPC we want to check that the Virtual_Axis.AverageVelocity is greater than zero.




Note that in this case the master axis is virtual. Now run the virtual axis from the VirtualAxis_Jog contact in the VirtualAxis code module. So when we ran the virtual axis is triggered a fault, we will modify the curve to soften the movement.





Axis01_MAPC_Controls*

We try running again and find that we are faulting on a position error. Open the Axis Properties for Axis01 and increase the position error to 20.0.




Now set up a trend. Add the actual and command position tags. Set the time scale to 45 seconds.



43. Adding the Second MAPC for Cam Bending


At this point there have been changes to the program in order to add the next MAPC. These changes are outlined in the next paragraphs.



Changing to a rotary axis and Setting the axis to roll over (position unwind) to 360 degrees saves us from having to home the axis.



In the above graphic we have changed the virtual axis speed to 10 (decreased).



Above is the rung we are adding. Note below that we are using the next cam profile, [2]. Start with 1-to-1 scaling and execution mode of once and schedule of pending. **Master Lock Position** and **Cam Lock Position** refer to the position value to be used as the “lock” point. In this case our highest master value is 110.66 so we choose 111.0 for our lock position. It is a point outside the range of movement but also where we want the axis to stop movement. (lock up) We are using the same 111.0 for **Cam**.

We are going to add some logic to our rung. First, we want to wait for the MAPC to complete (.PC) and then we will move a 3 into the CurrentState variable so we can repeat/loop.






Figure 5 selecting master and cam lock position.

We will also add a pending status, we want to know if the axis is in action. We can tell this via tag

Axis01.PositionCamPendingStatus. Next we add a latch for second cam active.





We will also have to add the SecondCam_Active latch to rung 4.




44. Showing a More In-Depth View of the Cams Blended with Added Features

“Blending” seems to refer to moving back and forth between two states each with its own MAPC function block. The key is to wait until one is done before starting the other, this is done with status bits, see above. So you can have two (or more?) axis running back to back presumably against the same virtual master. The transition between the two has to be seamless. Now we will run the below two cams and inspect the trend. Blending time cams works the same way.



Looks good.


Question is, how does this happen? Look at the first MAPC function block, it is set for Execution Mode: Once and Execution Schedule: Immediate.






Now the second MAPC instruction is set up for...
 Execution Mode: Once and
 Execution Schedule: Pending.

Important note: this only works because of the SecondCam_Active discrete bit “blocking” MAPC 2 until MAPC 1 is compete. Otherwise MAPC 2 would run continuously even with execution schedule set to pending.




45. Using the MCCP Instruction

Note that a CAM and a CAM Profile are not the same thing. The CAM Profile collects the data from the CAM and runs it. You can make changes to the CAM array but they will not be loaded into the CAM Profile until you fire the MCCP instruction. Also be careful of the Length field of the MCCP instruction, you can build a deeper cam. This section talks about loading new values into the CAM Profile during run time using the MOV command.



We've added to the UDT.




Now, what are the elements which make up the cam? We are not talking about the Cam Profile because we do not build the cam profile, we build the cam and load the cam profile.

Axis01AdvControl.PendingCam[1]	[...]	[...]	CAM
Axis01AdvControl.PendingCam[1].Master	0.48		REAL
Axis01AdvControl.PendingCam[1].SegmentType	1		DINT
Axis01AdvControl.PendingCam[1].Slave	0.5		REAL


Segment Type is the Linear or Cubic entry. Master and Slave are position entries.

47. Using a MCCP and then Loading it into an MAPC Instruction For Use


The idea of creating a CAM is to load it into a MATC or a MAPC. So how do we do that? We built a cam with MCCP, now how do we use that cam with the MCCP Cam Profile? The final CAM Profile we build we want to use in either a MATC or MAPC. Note that the axis cannot be running when you change the cam since you would be changing the dynamics of the servo.



Below code shows how to manipulate the cam values in run-time.




The above cam value manipulation code can be repeated for further configurations.



48. MAOC Introduction

MAOC is Motion Arm Output Cam. It is used in conjunction with motion to control output such as bit or IO you want to fire when the servo reaches a certain position.

Below dialog is the CAM of a MAOC instruction.



Below are the field headings.

[]	Output Bit	Latch Type	Unlatch Type	Left Position	Right Position	Duration	Enable Type	Enable Bit
0	0	Position	Position	0.250000	0.499999	0.000000	Input	0
1	0	Position	Position	0.750000	0.999999	0.000000	Input	0
2	1	Position and Enable	Position and Enable	0.500000	0.999999	0.000000	Input	1
3	2	Enable	Enable	0.000000	0.000000	0.000000	Input	2
4	3	Position	Duration	0.000000	0.000000	5.000000	Input	2
5	4	Enable	Duration and Enable	0.000000	0.000000	5.000000	Input	2
6	1	Position	Position	0.650000	0.750000	0.000000	Input	0
*								

First column, **Output Bit**. Outputs associated with the instruction, note the Output, Input, and Output Cam fields.

Latch Type: Position & Enable, Inactive, Position, and Position & Enable.

Latch Type Position is associated with **Left Position**.


Unlatch Type Position is associated with **Right Position**.



If **LatchType** is set to Inactive the output bit is left unchanged. Note output bits are reset when the enable bit becomes inactive.

Position and Enable means the output is reset when the axis position leaves the compensated range (cam range) and the enable bit becomes inactive (?).


For **Unlatch Type Duration and Enable** the output bit is reset when the duration expires and the enable bit becomes inactive. Duration means you want to keep the bit on for a set time. Duration and Enable means both are active. It sounds like “enabled” means if the other output bit in the cam is “on” the action of the bit you are configuring will take place.

More on this below.







Here red is the master cam which the output cam follows. Remember, on the trend the vertical axis is position of the master cam. Blue is the output bit, from the table we see it should be coming on at .25, off at .5, on again at .75, and off at 1. It does seem to be following that pattern. Now output bit 1; it should come on at .5 and off at 1, and it has another line that says come on at .65 and off at .75. Not seeing this, may have to do with enable bits?



Looking at the traces on the Output Cam we see everything seems correct.

50. MAOC Cam Output Control

Regarding outputs, if they are aliased to an output card and are active, meaning being driven by the cam, and the program is stopped (axis is stopped) suddenly (abnormally) the output remains high (or whatever the driven state is). Note that during this time the.IP bit will be on. So it is necessary to write code to put the outputs in the desired safe state.



Writing the zero to the MAOC Output parameter sets the output bits to zero.

Output_Cam.Output	4
Output_Cam.Output.0	0
Output_Cam.Output.1	0
Output_Cam.Output.2	1
Output_Cam.Output.3	0

51. MAOC Compensation Usage Explained

The screenshot shows the 'Tag Properties - MAOC_Compensation' dialog and two 'MAOC' configuration windows.

Tag Properties Dialog:

- Name:** MAOC_Compensation
- Description:** (empty)
- Type:** Base
- Alias For:** Predefined Data Type
- Data Type:** OUTPUT_COMPENSATION[10] (highlighted with a red dashed box)
- Scope:** MainProgram
- External Access:** Read/Write
- Style:** (dropdown menu)
- Constant:** (checkbox)

MAOC Configuration Windows:

- MAOC (Axis 0):**
 - Motion Control Output: Output_Cam.Enable_Control → 0 ←
 - Input: Output_Cam.Input → 4 ←
 - Output Cam Cam Start Position: Output_Cam.Clock[0] → Output_Cam.CAM_Start → 0.0 ←
 - Cam End Position: Output_Cam.CSM_End → 1.0 ←
 - Output Compensation: MAOC_Compensation[0]
 - Execution Mode: Continuous
 - Execution Schedule: Forward Only
 - Axis Arm Position: Output_Cam.Axis_Arm → 0.0 ←
 - Cam Arm Position: Output_Cam.CAM_Arm → 0.0 ←
 - Position Reference: Command
- MAOC (Axis 1):**
 - Motion Control Output: Output_Cam_Abs.Enable_Control → 0 ←
 - Input: Output_Cam.Input

When you create the compensation tag, keep in mind the type is in the predefined group of UDTs. Compensation data type can be declared in the program tag scope.

The screenshot shows a dialog for declaring the **OUTPUT_COMPENSATION** data type.


Members: Data Type Size: 24 byte(s)

Name	Data Type	Style	Description	External Access
Offset	REAL	Float		Read/Write
LatchDelay	REAL	Float		Read/Write
UnlatchDelay	REAL	Float		Read/Write
Mode	DINT	Decimal		Read/Write
CycleTime	REAL	Float		Read/Write
DutyCycle	REAL	Float		Read/Write

MAOC_Compensation	{...}	{...}		OUTPUT_COMP...
MAOC_Compensation[0]	{...}	{...}		OUTPUT_COMP...
MAOC_Compensation[0].Offset	0.0		Float	REAL
MAOC_Compensation[0].LatchDelay	0.5		Float	REAL
MAOC_Compensation[0].UnlatchDelay	0.5		Float	REAL
MAOC_Compensation[0].Mode	0		Decimal	DINT
MAOC_Compensation[0].CycleTime	0.0		Float	REAL
MAOC_Compensation[0].DutyCycle	0.0		Float	REAL

Output Compensation: array indices correspond to output bit numbers, the minimum size of an array is determined by the highest compensated output bit. Each bit has the 6 settings below:

- CycleTime: Refers to pulse rising edge in Inverted & Pulsed compensation (see diagram)
 DutyTime: = (On-Duty Time)/(Cycle Time), on-duty time + pulse width
 LatchDelay: provides time delay compensation for the latch operation
 Mode: normal, inverted , pulsed, inverted & pulsed
 Offset: provides position compensation
 UnLatchDelay: provides time delay compensation for the unlatch operation (inoperative)



The cam range is defined by the left and right cam positions of the Output Cam element. The compensated cam range is defined by the cam range, offset, and latch and unlatch offsets. The latch and unlatch offsets are defined by the current speed v.

$$\text{Latch Offset} = v * \text{Latch Delay}$$


$$\text{Unlatch Offset} = v * \text{Unlatch Delay}$$

The resulting compensation offset can actually be larger than the difference between cam start and cam end position. The following equation illustrates the effect of the compensation values on the duration of an Output Cam element:


$$\text{Compensated Duration} = \text{Duration} + \text{Latch Delay} - \text{Unlatch Delay}$$

Normal	The output bit is set, when the output of the latch and unlatch operation becomes active. The output bit is reset, when the output of the latch and unlatch operation becomes inactive.
Inverted	The output bit is set, when the output of the latch and unlatch operation becomes inactive. The output bit is reset, when the output of the latch and unlatch operation becomes active.
Pulsed	The output bit is pulsed, when the output of the latch and unlatch operation is active. The on-duty state of the pulse corresponds to the active state of the output bit. The output bit is reset, when the output of the latch and unlatch operation becomes inactive.
Inverted & Pulsed	The output bit is pulsed, when the output of the latch and unlatch operation is active. The on-duty state of the pulse corresponds to the inactive state of the output bit. The output bit is set, when the output of the latch and unlatch operation becomes inactive.


Below diagram illustrates the four modes described above.



The following diagram shows the effect of the selected unlatch type on the output bit for different compensated cam and enable bit combinations as function of **position**.




The following diagram shows the effect of the selected unlatch type on the output bit for different compensated cam and enable bit combinations as function of **time**.




The cam table from the program (sample below) will not necessarily show the effect of the above settings.


bit	[]	Output	Latch Type	Unlatch Type	Left Position	Right Position	Duration	Enable Type	Enable Bit
0	0	Position	Position		0.250000	0.499999	0.000000	Input	0
1	0	Position	Position		0.750000	0.999999	0.000000	Input	0
2	1	Position and E...	Position and En...		0.500000	0.999999	0.000000	Input	1
3	2	Enable	Enable		0.000000	0.000000	0.000000	Input	2
4	3	Position	Duration		0.000000	0.000000	5.000000	Input	2
5	4	Enable	Duration and E...		0.000000	0.000000	5.000000	Input	2
6	1	Position	Position		0.650000	0.750000	0.000000	Input	0
*									



Bit firing for above cam with no compensation. With compensation on bit 1 would be firing very close to the Master Axis initial position (position 1 is from .5 to almost the rollover).

Now we will add compensation and delays via the code shown below (MAOC Slot0.ADC).





Now, with compensation enabled, output 1 is firing very close to the beginning of cam 1. Here we have modified the compensation and delay values of the cam.

52. MAOC Input Enable Feature (Input Cam)

In this example our input cam is a parameter called `Output_Cam.Input`. Say we set our top three output cam rows to Position & Enable.

bit	0	0.2	0.4	0.6	0.8	1	^	I	Output Bit	Latch Type	Unlatch Type	Left Position	Right Position	Duration	Enable Type	Enable Bit
0								0	0 0	Position	Position and Enable	0.250000	0.499999	0.000000	Input	0
1								1 0	Position	Position and Enable	0.750000	0.999999	0.000000	Input	0	
2								2 1	Position and ...	Position and Enable	0.500000	0.999999	0.000000	Input	1	
3								3 2	Enable	Enable	0.000000	0.000000	0.000000	Input	2	
4								4 3	Position	Duration	0.000000	0.000000	5.000000	Input	2	
5								5 4	Enable	Duration and Enable	0.000000	0.000000	5.000000	Input	2	
6								6 1	Position	Position	0.650000	0.750000	0.000000	Input	0	
7								*								

Now we set the first three `Output_Cam.Input` values to 1, this will enable those bits.

- Output_Cam.Input	31
- Output_Cam.Input.0	1
- Output_Cam.Input.1	1
- Output_Cam.Input.2	1
- Output_Cam.Input.3	1
- Output_Cam.Input.4	1

Now we run and check the `Output_Cam.Output` bits...

- Output_Cam.Output		13
Output_Cam.Output.0		1
Output_Cam.Output.1		0
Output_Cam.Output.2		1
Output_Cam.Output.3		1
Output_Cam.Output.4		0

We find that bits 0, 1 and 2 are cycling. We can try to discern the pattern. Does it look like the cam profile? It appears that only bits 0 and 1 have a cam defined. Now we will change all Enable bits to “6”.


bit	0	60	120	180	240	^	[]	Output...	Latch ...	Unlatch...	Left P...	Right ...	Duration...	Enabl...	Enabl...
0							0	0	Position...	Position...	0.250...	0.499...	0.000...	Input	6
1							1	0	Position...	Position...	0.750...	0.999...	0.000...	Input	6
2							2	1	Position...	Position...	0.500...	0.999...	0.000...	Input	6
3							3	2	Enable	Enable	0.000...	0.000...	0.000...	Input	6
4							4	3	Position	Duration	0.000...	0.000...	5.000...	Input	6
5							5	4	Enable	Duration	0.000...	0.000...	5.000...	Input	6
6							6	1	Position	Position	0.650...	0.750...	0.000...	Input	6

Now restart the servo but you must also restart/recycle the cam profile. We are interested in the bits set to Position and Enable for Latch/Unlatch.

bit	0	1	^	[]	Output...	Latch Type	Unlatch Type
0		1		0	0	Position and Enable	Position and Enable
1		1		1	0	Position and Enable	Position and Enable
2				2	1	Position and Enable	Position and Enable
3				3	2	Enable	Enable
4				4	3	Position	Duration
5				5	4	Enable	Duration and Enable
6				6	1	Position and Enable	Position and Enable

The way we have the system configured we have no enables on (all are at 6) so we should not see any outputs responding. The positions set to 1 in the enable column will respond. We can run and actually see this in the code, the Output_Cam.Output value will change as the bit numbers which are responding to the cam change.


When all enable values are set to 6 no bits respond and Output_Cam.Output displays 10. Consider the Input_Cam.Input array, it has position 6 and beyond set to zero.



Now if we turn on Output_Cam.Input 6, set to 1, we will see different response.

Output_Cam.Input	95
Output_Cam.Input.0	1
Output_Cam.Input.1	1
Output_Cam.Input.2	1
Output_Cam.Input.3	1
Output_Cam.Input.4	1
Output_Cam.Input.5	0
Output_Cam.Input.6	1


We see cam outputs firing. So the bit number in the Enable column tells the system which Output_Cam.Input bit to look at and use it as the enable signal (1 being enable). That's pretty much our Output_Cam.Input array.




Now we ask, what if our Enable Type bit is set to Inverted Input? This means invert whatever the value is at Output_Cam.Input[#] and use that value as the enable signal. I believe these values can be changed at run time, in some cases the block enable has to be cycled but maybe not this case.

53. MAOC Axis Setup - Avoid an ERR

Consider the motion planner Output Cam Execution Targets setting in the virtual axis properties dialog for the “Axis” being used with the MAOC command.



If we leave the 0 here we will fail on an error when we run because the MAOC instruction is telling the Axis (in this case virtual) that it has output cams to execute and time must be set aside to do so. You must have a value here which is large enough to accommodate the output cam. This applies to real axis as well.




- Output_Cam.Enable_Control	{ ... }
- Output_Cam.Enable_Control.AC	0
- Output_Cam.Enable_Control.ACCEL	0
- Output_Cam.Enable_Control.CalculatedDataAvailable	0
- Output_Cam.Enable_Control.DECCEL	0
- Output_Cam.Enable_Control.DN	0
- Output_Cam.Enable_Control.EN	0
- Output_Cam.Enable_Control.ER	1
+ (Output_Cam.Enable_Control.ERR)	35
+ Output_Cam.Enable_Control.EXERR	0
+ Output_Cam.Enable_Control.Flags	301989888
- Output_Cam.Enable_Control.IP	0
- Output_Cam.Enable_Control.PC	0
+ Output_Cam.Enable_Control.SEGMENT	0
+ Output_Cam.Enable_Control.STATE	0
+ Output_Cam.Enable_Control.STATUS	0
- Output_Cam.Enable_Control.TrackingMaster	0

35	The specified execution target exceeds the number of Output Cam targets configured for the axis.	Illegal Execution Target
----	--	--------------------------


To fix this error, the motion planner execution target value should meet or exceed the value of Output_Cam.Input.

54. MAOC Cam Used In a Linear

What is the best application for a MAOC? Usually a rotary axis is used, this is because of the rollover (unwind value). Have a look at our emulated application...



So our position unwind is 200000 with a conversion constant of 8000 gives us 25 revolutions per reset/rollover.



Now we have configured this linear axis to run to position 1000 and then the .PC bit will fire which will clear Axis[0].Axis_MAM[0].Enable and set Axis[0].Axis_MAM[1].Enable.


What Axis[0].Axis_MAM[1].Enable does is run back to zero. After which it will disable itself and enable the original axis so it can run to 1000 again. Process continues.

While this is happening a MAOC is firing off the positions. You can use the MAOC to do this but is it the best application for this instruction? Best way to implement this function? Maybe not.

Note that during the above scenario the MAOC Execution Schedule is set to Bi-Directional. This tells MAOC to execute the cam in both directions.

55. MAOC Code Explained

Explanation of the MAOC code. Be aware of setting Position Reference, can be Command of Actual.
Actual = use the encoder of the motor, this is more accurate
Command = use the position commanded, most system use this command.




Be aware of **Motion Disable Output Cam**, here we are invoking it when ActionStatus is off and the MAOC declaration tag is done (.ip = true). It is very important to issue this command in order to disable cam outputs, this is you putting the machine in a safe condition. Otherwise the outputs remain active after shutdown.

Moving a zero into Output_Cam.Output will shutdown the cam action (all disabled).
Output_Cam_Abs.Output is the same thing on the other axis.

56. MAOC Update



We will create a motion output cam using a MAOC instruction following the position of a servo to actually control an actual output card. In this exercise we are using a hardware / real servo axis. This is a position based system.

Item 1: make sure your output card is set up for Scheduled Data. Found in the cards properties dialog.




Schedule Data allows the program to go in and control the outputs through the MAOC command.


Note our Drive Resolution: 2000 Drive counts per Motor Rev is equal to the Conversion Constant so that we have one revolution per actual cycle.




This is the cam profile we will run.



Note Latch Type = Position and Unlatch Type = Duration, so you will trigger on position and unlatch after a certain duration.



Sawtooth is the master position rollover, green and blue are outputs.





Above we have added a bit in parallel for moving zeros into the Output_Cam.Output and Output_Cam_Abs.Output bits which shutdown the physical outputs (safe state), see previous chapter. The new bit is just saying anytime Axis 0 Jog is not in progress and Output_Cam.Enable_Control.IP is in progress we can shutdown the output bits and issue the MDOC instruction (motion disarm output cam).

Key Points on MAOC:

- **Be aware of how your axis is set up.**
- **When not running ISSUE MDOC TO SHUTOFF YOUR MAOC!**

57. Using a Axis StandStill Bit

Say you want to make sure the servo is absolutely stopped. To achieve this by using **VelocityStandstillStatus**. This status bit is telling you the servo has absolutely no velocity. But there will be times when the axis is moving very slowly and this will hang up your process. We can adjust the standstill window using SSV. You can see this effect when a servo is not tuned properly and is hunting for the setpoint.



Axis01.VelocityOffset	0.0
Axis01.VelocityStandstillStatus	1
Axis01.VelocityThresholdStatus	0
Axis01.WatchEventArmedStatus	0

58. Intro to a Coordinated Motion

From servo CS_XY we can see how our activity is set up.

Coordinate System Properties - CS_XY




General		Geometry	Units	Offsets	Dynamics	Motion Planner	Tag	
Motion Group:		HyTechMotion					<input type="button" value="..."/>	New Group...
Type:		Cartesian					<input type="button" value="..."/>	
Dimension:		<input type="button" value="2"/>	Transform Dimension: <input type="button" value="0"/>					
	Coordinate	Axis Name			Coordination Mode			
0	X1	XAxisV			Primary			
1	X2	YAxisV			Primary			


Coordinate System Properties - CS_XY

General		Geometry	Units	Offsets	Dynamics	Motion Planner	Tag
Type: Cartesian Transform Dimension: 0							
Link Lengths							
L1: <input type="text" value="0.0"/>							
L2: <input type="text" value="0.0"/>							
Zero Angle Orientations							
Z1: <input type="text" value="0.0"/>	Degrees						
Z2: <input type="text" value="0.0"/>	Degrees						
Z3: <input type="text" value="0.0"/>	Degrees						



Coordinate System Properties - CS_XY


General		Geometry	Units	Offsets	Dynamics	Motion Planner	Tag
Coordination Units: <input type="button" value="Coordination Units"/>							
Axis Name		Conversion Ratio		Conversion Ratio Units			
XAxisV	1.0	/	1	Position Units/Coordination Units			
YAxisV	1.0	/	1	Position Units/Coordination Units			






And our plot...







This is what the same pen would look like as a time based trend...




Note that there are two pens, even in XY Plot mode they give different traces.




59. Coordinated Motion Section






Standard motion group.




Now configure the axis... The X and Y axis are virtual axis.




To create a cartesian axis system... Create a new tag of type COORDINATE_SYSTEM.
 Coordinate System is really referring to Coordinated System.



Types of coordinated systems include ...



The command for a circular movement is **Motion Coordinated Circular Move (MCCM)**.



Our motion instruction has a new output bit, .AC. This stands for:

When you have a coordinated move instruction queued, the Active bit lets you know which instruction is controlling the motion. It sets when the coordinated move becomes active. It is reset when the Process Complete bit is set or when the instruction is stopped.

60. Coordinated Motion Section

Motion Coordinated Linear Move (MCLM)

Use the MCLM instruction to start a single or multi-dimensional linear coordinated move for the specified axes within a Cartesian coordinate system. You can define the new position as either absolute or incremental.

The Motion Coordinated Linear Move (MCLM) instruction performs a linear move using up to three (3) axes statically coupled as primary axes in a Cartesian coordinate system. You specify whether to use an absolute or incremental target position, the desired speed, maximum acceleration, maximum deceleration, acceleration jerk, deceleration jerk, and the units of each. The actual speed is a function of the programmed units of the speed (Units per sec, or % of Maximum, as configured for the coordinate system), and the combination of primary axes that are commanded to move. Each axis is commanded to move at a speed that allows all axes to reach the programmed endpoint (target position) at the same time.

Dwells

You have the option to program a dwell using Time Based Programming in either Time Driven Mode or MDSC Mode when a zero length move (see Zero Length Move below) is programmed. The acceleration, deceleration, and jerk parameters are ignored when a zero length move is programmed. Therefore, when in time driven mode, the duration of the dwell is in seconds. When in MDSC mode, the duration of the dwell is programmed in units of Master Distance.

In MDSC mode, the dwell starts either at the Master Lock Position or immediately, depending on the programmed Lock Direction parameter, and continues for a duration as specified in the Speed parameter.

Zero Length Move

In Master Driven Mode and Time Driven Mode, you have the option of configuring a move with a Slave distance increment of zero (or a move with the same target and current position). If speed is specified in Master Units, the move remains active until the specified Master distance has been traversed. Use this type of move to generate a dwell in a multi-segment path move.


Similarly, when you program the move time directly in seconds in Time Driven Mode, a move of the duration of X seconds with a zero departure results in a programmed delay of the specified time.

Instructions with zero length cause velocity of the multi-axis instruction preceding the one with zero length to decelerate to zero at its endpoint. To avoid this behavior, it is suggested that you eliminated moves with zero length from your program.

MCLM				
Motion Coordinated Linear Move		(EN)		
Coordinate System	CS_XY	(DN)		
Motion Control	MCLM_PATH2D_DRAW1	(ER)		
Move Type	DrawPath[PathIndex].MoveType	(IP)		
	0	(AC)		
Position	DrawPath[PathIndex].Position[0]	(PC)		
XAxisV	??			
YAxisV	??			
Speed	PathSpeed			
	3.0			
Speed Units	Units per sec			
Accel Rate	PathAccelTrapezoidal			
	20.0			
Accel Units	Units per sec ²			
Decel Rate	PathDecelTrapezoidal			
	20.0			
Decel Units	Units per sec ²			
Profile	Trapezoidal			
Accel Jerk	100.0			
Decel Jerk	100.0			
Jerk Units	% of Time			
Termination Type	TermType			
	1			
Merge	Disabled			
Merge Speed	Current			
Command Tolerance	0			
Lock Position	0			
Lock Direction	None			
Event Distance	0			
Calculated Data	0			
^				


Operand	Type	Format	Description
Coordinate System	COORDINATE_SYSTEM	Tag	Coordinated group of axes.
Motion Control	MOTION_INSTRUCTION	Tag	Structure used to access instruction status parameters.
Move Type	SINT, INT, or DINT	Immediate or Tag	Select the Move Type: 0 = Absolute 1 = Incremental
Position	REAL	Array tag []	[coordination units]
Speed	SINT, INT, DINT, or REAL	Immediate or Tag	[coordination units]
Speed Units	SINT, INT, DINT, or REAL	Immediate	0 = Units per Sec 1 = % of Maximum 4 = Units per MasterUnit 7 = Master Units
Accel Rate	SINT, INT, DINT, or REAL	Immediate or Tag	[coordination units]
Accel Units	SINT, INT, or DINT	Immediate	0 = Units per Sec ² 1 = % of Maximum 4 = Units per MasterUnit ² 7 = Master Units
Decel Rate	SINT, INT, DINT, or REAL	Immediate or Tag	[coordination units]
Decel Units	SINT, INT, or DINT	Immediate	0 = Units per Sec ² 1 = % of Maximum 4 = Units per MasterUnit ² 7 = Master Units
Profile	SINT, INT, or DINT	Immediate	0 = Trapezoidal 1 = S-curve
Accel Jerk	SINT, INT, DINT, or REAL	Immediate or Tag	You must always enter values for the Accel and Decel Jerk operands. This instruction only uses the values if the Profile operand is configured as S-curve. Enter the jerk rates in these Jerk Units. 0 = Units per sec ³ 1 = % of Maximum 2 = % of Time 4 = Units per MasterUnit ³ 6 = % of Time-Master Driven 7 = Master Units
Decel Jerk	SINT, INT, DINT, or REAL	Immediate or Tag	Use these values to get started. Accel Jerk = 100 (% of Time) Decel Jerk = 100 (% of Time) Jerk Units = 2
Jerk Units	SINT, INT, or DINT	Immediate or Tag	

In our example the MCLM instruction uses indirect addressing for the Move Type tag. What they are doing is changing between type 0 (absolute) and type 1 (incremental) depending on which line segment is being calculated and drawn.




61. Coordinated Motion Section

We begin the Run_Example_CirDSqr module by homing the two axis. Cycle Stop PB will do the same.




Once homing is complete we transition to MotionCircleDiamondSquare.




The FAL instructions make use of parameters FAL51.POS as an index into the path array. But what is it? Note FAL51 is the name of the control tag.

- DestPath[1].Position	{ ... }
DestPath[1].Position[0]	0.0
DestPath[1].Position[1]	2.0
DestPath[1].Position[2]	0.0

If you follow the DestPath[#].Position[#] parameter in the program tags area you'll see that the path entries change as you move through the DestPath[] index.




What happened here? The course rate update and the speed settings we have entered are not capable of creating the path trace we want. Note that Termination Type directly effects the course rate update (?). Basically, the x and y axis have to move so fast to make the speed they cannot create the trace we want.



MCCM_PATH2D_DRAW1.IP

The way we tell if a move is in process is the IP bit.



- DrawPath	{...}
- DrawPath[0]	{...}
+ DrawPath[0].CircleType	0
+ DrawPath[0].Direction	0
+ DrawPath[0].InstructionType	0
+ DrawPath[0].MoveType	1
+ DrawPath[0].Position	{...}
+ DrawPath[0].ViaCenterRadius	{...}

62. Kinetix 6000 Inputs




I/O Connector Pinout

Table 27 - IAM/AM I/O 26-pin (IOD) Connector

IOD Pin	Description	Signal
1	Hardware enable 24V DC power supply	+24V_PWR
2	Hardware enable input	ENABLE
3	Common	+24V_COM
4	Home switch 24V DC power supply	+24V_PWR
5	Home switch input	HOME
6	Common	+24V_COM
7	Positive overtravel 24V DC power supply	+24V_PWR
8	Positive overtravel limit switch input	OT+
9	Common	+24V_COM
10	Negative overtravel 24V DC power supply	+24V_PWR
11	Negative overtravel limit switch input	OT-
12	Common	+24V_COM
13	24V registration power	REG_24V



IOD Pin	Description	Signal
14	High speed registration 1 input	REG1
15	Common for registration	REG_COM
16	24V registration power	REG_24V
17	High speed registration 2 input	REG2
18	Common for registration	REG_COM
19	Reserved	-
20	Reserved	-
21	Reserved	-
22	Reserved	-
23	Analog output 0	DAC0
24	Analog output common	DAC_COM
25	Analog output 1	DAC1
26	Analog output common	DAC_COM

Figure 26 - Pin Orientation for 26-pin I/O (IOD) Connector





63. Understanding Servo Registration

Here we will look at the Motion Arm Registration (MAR) and Motion Disarm Registration (MDR) instructions.



We can configure the routine to run on the event trigger “Axis Registration 1”. TRN_Servo is the tag associated with the physical axis.


Again, **our routine triggers on the registration event.**




Key point is that the MAR instruction has to be enabled/re-armed each time you have to use it. This arming action tells the drive to monitor the registration bit more frequently, assigns it to a task running at a higher frequency. So trying to use the registration input when not armed is dicey at best, could miss the signal. **Arm the MAR instruction each time you need to use it.**


The MAR IP bit has to register each time you use the MAR instruction or the next time you try to use it the function will not preform properly. Register IP, register DN, and then re-arm for next event.

64. Length Detection Example (A deeper look into Registration)




Bottom rung: we get the servo position, which at this point is the registration position, when TRN_Servo_MAR activity is complete. We will use this value in the product tracking routine, this is an event driven task on the registration input of the servo we are running. The idea here is we using this value in a calculation to determine the product length (this is an oversimplified example, an actual length measurement application would be much more involved).






Trend of the length measurement application.




Length measurement code. This is not the entire application. Takes position each time .PC comes on.



RW: If your application requires rapid and continuous detection of a registration sensor, **we recommend using this logic.**

65 Servo Registration Using a Photo-Eye (Real-World Design)

The modified code below more closely suits a real-world application. The registration is now part of the mechanism, so we get consistent length even when we slow speed the drive.



Improved application more closely resembling a real-world application.

Remember, event must be armed each time the input is going to fire. And every registration application will be unique and reflect the real-world process.

66. Servo Home Failed Because a Servo Event Armed

What happens if you try to home your servo and there is an armed registration? You will get a fault. You cannot home an axis which is in registration.


Motion Direct Commands - TRN_Servo:7, MAH, (16#0000) No Error
Motion Direct Commands - TRN_Servo:8, Execution Error.MAH, (16#0022) You are trying to start a Motion Axis Home (MAH) command while running a registration.

Here is a workaround using direct motion toolbox.

Right click on axis, select Motion Direct Commands.

Select Motion Disarm Registration (MDR) from the left hand pane tree.

Select the Input Number to correspond to the number being used in the MAR instruction.




Click the Register button on the Motion Direct Command dialog.

Now select the MAH command in Motion Direct Command dialog and click on Execute.


Now, what is your registration position when you capture it?

TRN_Servo.ActualPosition -0.000015

It is essentially zero.



This code modification, and the one on the following page, fixes the problem with homing described above.



67. Closing Comments

He is discussing Advanced Servo Motion Mastery 2, a course which never came to fruition.